

# ***User Manual***

## **Video Doorbell**



Model: VD1/DBW5

## Table of Contents

---

Security Warning.....	1
1 Overview.....	2
1.1 Key Features.....	2
1.2 Read before Use.....	3
1.3 Packing Contents.....	3
1.4 Physical Description.....	3
1.5 SD Card Management.....	4
1.6 Add Device: Connection via the Foscam App.....	5
1.7 Installation.....	5
2 Access the IP Camera in Foscam App.....	6
2.1 Foscam APP Surveillance Window.....	6
2.2 Watch Live.....	7
2.3 Camera Setting.....	11
3 Surveillance Software Foscam VMS.....	22
3.1 Hardware Connection & Software Installation.....	22
3.2 Create Account.....	22
3.3 Add Device.....	23
3.4 Surveillance Software GUI.....	31
3.5 Advanced Camera Settings.....	35
4 Appendix.....	65
4.1 Frequently Asked Questions.....	65
4.2 Default Parameters.....	69
4.3 Specification.....	69
4.4 CE & FCC.....	70
4.5 WARRANTY.....	71
4.6 Statement.....	74
5 Obtaining Technical Support.....	75

# Security Warning

---

- Please change the password of your doorbell regularly, using a combination of numbers, letters and special characters.
- We recommend that you regularly update your doorbell to the latest available software and firmware versions to help ensure the best experience for your doorbell.

# 1 Overview

Welcome to use our product, Video Doorbell. Foscam Video Doorbell is an integrated IP Camera with a color CMOS sensor enabling viewing in High Definition resolution. It combines a high quality digital video camera, with a powerful free Foscam Video Management Software, to bring clear video to your desktop from anywhere on your network or over the APP.

It supports P2P function. Thanks to the P2P easy access technology, you don't need to do complicated Port Forwarding and DDNS settings, you just need to scan the QR code on the side of the camera to connect it on smart phone, or input the UID on CMS software to realize remote access.

The Doorbell supports the industry-standard H.264+ compression technology, drastically reducing file sizes and conserving valuable network bandwidth.

The doorbell is specially designed for your access control monitoring application, such as courtyard door, home door. you'll always be connected to your home, so you can watch over your property and answer the door from anywhere. See who's at your door, prevent crime and protect your home – all from your phone, tablet or PC.

## 1.1 Key Features

- ◆ 4.0 Megapixels Resolution, support HDR
- ◆ Supports WPA and WPA2 Encryption
- ◆ Support full duplex real-time 2-way Audio
- ◆ Ultra wide Angle lens, diagonal Angle up to 170°
- ◆ Supports AI algorithm (Face recognition)
- ◆ Support 2.4GHz & 5GHz dual-band WiFi
- ◆ Supports image snapshot
- ◆ Supports dual-stream
- ◆ Built-in High efficiency IR LED, has excellent night vision image
- ◆ Supports remote viewing & record from anywhere anytime
- ◆ Multi-level users management with password protection
- ◆ Supports multiple network protocols: IP、TCP、UDP、FTP、DHCP、RTSP、
- ◆ Providing Video Management Software to manage or monitor multi-cameras
- ◆ Supports sound detection
- ◆ Supports Alexa
- ◆ Supports Google Assistant
- ◆ Complete mounting bracket and kit are available
- ◆ Supports 128G Micro SD Card Storage(External)

## 1.2 Read before Use


Please first verify that all contents received are complete according to the Package Contents listed below. Before the Network Camera is installed, please carefully read and follow the instructions in the Quick Setup Guide to avoid damage due to faulty assembly and installation. This also ensures the product is used properly as intended.

## 1.3 Packing Contents


• Video Doorbell × 1	• 5° Vertical angle bracket × 1
• 15° Horizontal angle bracket × 1	• Ethernet Cable × 1
• Thick mounting bracket × 1	• Mounting bracket × 1
• Type-c cable × 1	• Power Kit × 1
• Wire Extenders × 2	• Wire Nuts × 2
• Dual-purpose screwdriver × 1	• Silicone Plug × 1
• Quick Setup Guide × 1	• Drill Hole Position Template × 1
• Expansion Screws × 1	

## 1.4 Physical Description

Front Panel



Rear Panel



**Camera:** Ultra wide Angle lens


**Microphone:** Built-in Microphone.

**Reset:** Press and hold on the reset button for 10 seconds. Releasing the reset button, the password will back to the factory default administrator password.

**Micro SD Card slot:** Supports up to 128GB SD card for storing the video.

**Power Input Port:** AC wiring interface.

**Type-C Port:** Use with C-type cable and 5V DC power distribution network.




**Speaker:** Built-in speaker

**Security screw hole:** Used to install anti-theft screws to prevent the doorbell from being stolen.

**NOTE:** There are up to two labels located at the bottom of the camera, this is an important feature of original Foscam cameras. If your camera does not have labels, it may be a clone. Cloned Foscam cameras can not use original firmware and are not eligible for warranty or technical services.

## 1.5 SD Card Management



The record files of the IP camera can be stored in the Micro SD Card.

This camera supports Micro SD Card and the max size of Micro SD card must be under 128G.

You need open the silicone plug, then plug the Micro SD card into Micro SD card slot inside the IP camera.

When you plug in the Micro SD card during the camera work process, please reboot the camera again, or else

the Micro SD Card may be cannot work well. When you re-install the cover, please ensure the tightness with the camera.

**Warning:** After installing the Micro SD card, please cover the silicone plug in time to prevent water or steam from falling into the device, causing damage.

## 1.6 Add Device: Connection via the Foscam App

Scan the QR code below to download and install the Foscam APP.



Please refer to the **Quick Setup Guide**.

It is strongly recommended that you complete the "add devices" process on the Foscam app before the doorbell hardware is installed.

You can scan the following QR code to watch the added video



## 1.7 Installation

Please refer to the **Quick Setup Guide**.

Note: Make sure you have installed the Foscam App, and have scanned the doorbell QR code and completed the "add device" process in the app before beginning the hardware installation process.

You can scan the QR code below to search and watch the power kit installation video.




## 2 Access the IP Camera in Foscam App

After setting up your Doorbell in the app, select it this will bring you to the Device Dashboard, where you can change settings and access various features.

### 2.1 Foscam APP Surveillance Window

Please refer to the [section 1.6](#) if you install the camera for the first time. You can start to learn about software operation after finish quick installation. When you launch the Foscam App, the devices page displays.



**Camera Name:** A camera name which is displayed in the Foscam Cloud Service.

You can rename your camera's name by tap Live  > Camera Settings  > Camera Info .

**OSD:** Including camera name and camera time, camera name can not be renamed but camera time can be in





synchronized with the phone.


**Sync Time:** Tap **Live**  > **Camera Settings**  > **Sync Time** .

**Camera Date&Time:** You can Sync Time, tap **Live**  > **Camera Settings**  > **Advanced Settings** > **Sync Time**.


**Face service:** face service is the intelligent classification of the face captured by your camera alarm detection through AI algorithm.

**Share:** You can share the camera with your family or other users to watch, tap **Live**  > **Camera Settings**  > **Share Camera** > **Family or Invite**.

**Cloud Service:** Foscam Cloud can save every alarm detection videos in ht cloud, and you can review every event anywhere, any time.


**More:** Click  the button to enter the more options page of the camera, Album, Alarm Settings, Playback, Notification, Sleep Mode, Settings.


**Add Device:** Please refer to the **Quick Setup Guide**.

**Split Screen:** Click  button, you can watch the live interface of 4 devices.



## 2. 2 Watch Live

Tap **Live**  to view and listen to a live video



**Back:** To stop viewing and listening to the live feed, tap the **Back**.

**Resolution:** There are three types to identify different streams you have set. If select the QHD Mode, the clearer video will become, and it will take up more bandwidth; If select the HD Mode, the video will not be as clear as QHD Mode, and it will take up less bandwidth. The FHD Model is a value between FHD Mode and SD Mode.

**Resolution:** Generally speaking, the larger the bit rate is, the clearer video will become. But the bit rate configuration should combine well with the network bandwidth. When the bandwidth is very narrow, and bit rate is large, that will lead to video can not play well.

On this screen, you can listen to a live stream, record clips, take a snapshot, activate two-way talk or full screen.

If you want to catch the smaller details, pinch and drag any image as you do with photos on your smart phone.

**Speaker / Mute the audio:** Here you can see if there is a Speaker or muted.

**Video:** Click this button to start the recording function.

**Snapshot:** Click this button to Snapshot the image.

**Two-way audio:** Press and hold this button to enable microphone intercom.

**Date:** Show date, Display the date, you can select the date through “<” or “>”button.

**Timeline:** If you have purchased cloud service, you can click the timeline to watch the storage video at the corresponding time on the cloud.

**Camera Setting:** Click this button to set more.

**IR LED Schedule:** On this page, you can enable/disable the IR LED, and set the IR auto switch or you can schedule it.

Auto: As default, the IR-Cut auto switch is ON, it means that the IR LED will be OFF during 9:00~18:00, and the IR LED will be ON at the other time.

Day: it means that the IR LED will be OFF all the time.

Night: it means that the IR LED will be ON all the time.

Schedule: You can schedule the time to turn the IR LED OFF/ON.

**Mirror:** You can flip the image horizontally with this button.

**Wired connection / Wireless connection:** You can use this to see whether the current camera is in a wired or wireless connection.

**Bit Rate:** You can see the current connection bit rate.

**Full screen:** Click this full screen button, you can live in full screen.


**More Function:** Here you can set Motion Detection and Sound Detection.

**Note:** Motion Detection and face Detection cannot be turned on at the same time.




**Motion Detection:**To enable motion detection, follow the steps below:

- 1 Enable Motion Detection button
- 2 Sensitivity---- It supports three modes: Low, Middle and High. The higher the sensitivity, the camera will be more easily alarmed. Select one motion sensitivity.
- 3 Triggered Interval----The interval time between two motion detection. Here supports 5s/6s/7s/8s/9s/10s/11s/12s/13s/14s/15s. Select one interval time.
- 4 Alarm recording duration---- The recording time of the alarm. Here supports 10s/30s/60s/120s. Select a recording time.
- 5 Schedule: Click the rectangle in the day of the week, and the corresponding time setting will be selected. For example, click "Sun", the time "00:00~24:00" will be set in "Sun", which means that when there is an object moving in the detection area, the APP will receive the camera's Motion alarm Push messages.



6 Detection area: Drag the selection box to select the alarm area,click back to pop up Save or Cancel, select save.



**NOTE:** You must set the detection area and detection schedule, or else there is no alarm anywhere and anytime.


face Detection: Turn on the face detection, if you turned on the Motion Detection before, it will automatically turn off the Motion Detection after turning it on. After opening, if a face is detected, the APP will receive an alarm push message from the camera.

Sound Detection: To enable Sound detection, follow the steps below:

- 1 Enable Sound Detection button
- 2 Sensitivity---- It supports three modes: Low, Middle and High. The higher the sensitivity, the


camera will be more easily alarmed. Select a Sound sensitivity.

- 3 Schedule: Click the rectangle in the day of the week, and the corresponding time setting will be selected. For example, click "Sun", the time "00:00~24:00" will be set in "Sun", which means that when there is an object moving in the detection area, the APP will receive the camera's Face alarm Push messages.



## 2.3 Camera Setting

Tap  the button, goes to Device Settings to make advanced camera settings.



### 2.3.1 My Plan

Here you can choose a 7-day free cloud service experience, and you can also purchase related cloud packages according to your needs. After successful activation, you can enjoy storing videos on the cloud anytime, anywhere.

### 2.3.2 Alarm

Click this button, and then you can refer to More Function in **2.2**



## Alarm Settings


The camera triggers different types of alarms based on different scenes and pushes alarm notifications to the user. The device that purchased the cloud service will also upload alarm recordings to the cloud storage.

Motion Detection ON >


Sound Detection OFF >

### 2.3.3 SD Card

If you have an SD card on your device, click this button to enter the SD-Card Video Playback. You can filter the corresponding videos according to the time and type.



#### Settings

Click  the button enter to SD Card settings, you can set SD card info and Recording Schedule.




## SD card settings


SD card info >

Recording Schedule >





## SD card info

Click the  button enter to SD Card settings, you can view the SD card storage information from this page, and you can also format the SD card.



## Recording Schedule


Click the  button enter to Recording Schedule setting, you can setting Loop Coverage, Voice Recording and Recording Schedule. Click Recording Schedule set and then click the rectangle in the day of the week, and the corresponding time setting will be selected. For example, click "Sun", the time "00:00~24:00" will be set in "Sun", which means that during this time period, the camera will automatically record to the SD card.



## 2.3.4 Firmware


You can see the current camera's firmware version and whether there is new software that needs to be upgraded. If there is new firmware, you can click the "Upgrade" button to upgrade.





## 2.3.5 Camera Info

You can see the basic information of the camera through this, such as Camera name, UID, MAC ID and firmware version information.



## 2.3.6 Share Camera

If you set up family members in my family, you can share the camera with your family here. Or you can invite other users to watch the live broadcast in the form of username and account information.

<

Invite

Invited Account

Nickname

Account

Share Time

☒ 3 Days

☐ 7 Days

☐ 30 Days

☐ 90 Days

☐ 180 Days

☐ Permanent

Sharing Permissions

Live Video


Share

## 2.3.7 Face


face service is the intelligen classification of the face captured by your camera alarm detection through AI algorithm.

<

Face



You haven't purchased the service, the face classification function cannot work.




Face service is the intelligent classification of the face captured by your camera alarm detection through AI algorithm.

Buy Now


## 2.3.8 Door Chime

You can choose the corresponding Chime type according to the Chime method in your home.



## 2.3.9 Privacy mask

This can be used to set certain masks as private areas on the video. Click + draw a mask area on the video , the mask area will be black on the video .Click the back button, the save page appears, click save, click Save to take effect.



Back to the surveillance window, you can see the mask area as the following picture:



## 2.3.10 WiFi Settings

If you selected Wired Connection via the Foscam, Tap the “WiFi Settings” button > select your WiFi network and enter your WiFi’s password. After setting up successfully, you can view live video without the Ethernet cable.



## 2.3.11 Sleep Mode

Most settings options are not available while camera is in sleep mode. If you want to enable settings and keep camera running, please turn off this mode.

## 2.3.12 Advanced Settings

Click on advanced settings to enter the advanced settings page, where you can set Security Settings, Ringtone, Light Settings, Power Frequency, Power Status, Smart Control, Wi-Fi Detection, Sync Time, Reset Device, NVR Connection, Video Settings, Prompt Settings, Screen Flip and Camera Speaker Volume settings.

### Security Settings

You can modify the username and password of the camera here.

### Ringtone

Here you can set the call ringtone and Push notification Ring



### Light Settings

On this page you can set the IR LED Settings and White Light.



### Power Frequency

You can see the battery status and power supply type from here.

**Note:** When DC power is used on the Type-C connector a mechanical chime and digital chime are not supported.

### Smart Control

On this page you can set Device Name and Region.

**Note:** Please select the corresponding to the area where you third-party smart speaker account is registered. If the connection is abnormal, you can try to change the area or contact Foscam customer service or contact third-party customer service to change the area registered by Alexa app.

### Wi-Fi Detection

Click Wi-Fi Detection to enter the Wi-Fi Detection page, tap Start Test, it will jump to the third party to check your current bandwidth speed.

### Sync Time

On this page, you can set the camera time, which can be synchronized with the phone time or NTP auto Sync and you can also select the time zone.

### Reset Device

You can reset your camera from here.

### NVR Connection

If your device has been added to one of FN7108HE / FN3109H / FN3104H, please be sure to turn on this switch, otherwise the recording will be unsuccessful, and your live broadcast screen will switch to 720p. If it is

not added under NVR, please close it.

### Video Settings

On this page you can set show time Overlay, Network Auto-Adaptability, HDR and Prompt Settings.

Video Settings

Show Time Overlay	<input checked="" type="checkbox"/>
Network Auto-Adaptability	<input type="checkbox"/>
HDR	<input type="checkbox"/>

### Prompt Settings

On this page you can set Status LED and Voice Prompt

Prompt Settings

Status LED	<input checked="" type="checkbox"/>
Voice Prompt	<input type="checkbox"/>

### Screen Flip

On this page you can set Screen Flip

Screen Flip

Horizontal Flip	<input type="checkbox"/>
-----------------	--------------------------

### Camera Speaker Volume

On this page you can set Camera Speaker Volume, you can adjust the volume by dragging.

Camera Speaker Volume

-


+

## 2.3.13 Reboot Camera

Click **Reboot** to reboot the camera. This is similar to unplugging the power to the camera.


### 2.3.14 Delete camera

You can click the delete Camera button to delete the camera from the app, or delete and keep history files from the app.




## 3 Surveillance Software Foscam VMS

### 3.1 Hardware Connection & Software Installation



1. Connect the camera to the network, make sure it is on the same network as the computer
2. You can download the "Foscam VMS" Windows version from [foscam.com/vms](http://foscam.com/vms) , and can download the "Foscam VMS" Mac version from the APP store:  
<https://apps.apple.com/cn/app/foscamvms/id1521202507?mt=12>  
Download and install according to the installation wizard.




### 3.2 Create Account

You can create a local administrator account.

For security, it is strongly recommended to create local accounts and password management, which prevents the entry of intruders.






you haven't created a local administrator account, please click Create Account to create.

After creating a local administrator account, you can:


1. Use the account to log in to the client to ensure information security.
2. Create sub-accounts and assign different permissions for management.



## 3.3 Add Device

### 3.3.1 LAN Add

If your doorbell is wired connect, you can choose the following method to add to FoscamVMS.



Click **Add Device**  button, then follow below steps:

**Step1** Select “ALL” from the device types.

**Step2** Click the IP address of the camera on the list, then the name of the camera and the IP information will be entered automatically.

**Step 3** Click Add.

Add Device

Device type :

☒ All
 ☐ IPC
 ☐ NVR

Refresh

Name	Device type	IP	Port	MAC
Foscam_Camera	IPC	192.168.1.246	88	A0EE6F154E85

+ Connect the camera to WIFI

1 device(s)

Add

Cancel

Manual add

**Step 4** Enter the username and password of the camera.

✕
Device account

Please enter the device account and password for your device.

Device account :

Password :

Add
Cancel

**Please Note:** Make sure the camera and PC are both in the same Local Area Network (LAN).

### 3.3.2 Manual add via IP

You can add the camera use manual add via IP also. Click the Manual add first, then follow below steps:

✕
Add Device

Device type :

☒ All
 ☐ IPC
 ☐ NVR

↻ Refresh

Name	Device type	IP	Port	MAC
Foscam_Camera	IPC	192.168.1.246	88	A0EE6F154E85

+ Connect the camera to WIFI
?

1 device(s)

Add
Cancel
Manual add

**Step 1** Select the IP address from Connection Mode

**Step 2** Enter the IP and Port of the camera.

**Step 3** Select "IPC" or "NVR" from the Device types.

**Step 4** Click Add

Add Device

Connection mode :

☐ UID

☐ DDNS

Port :

☒ IP address

Port :

88

Device type :

☒ IPC

☐ NVR

Add

Cancel

LAN add

**Step 6** Enter the username and password of the camera.

Device account

Please enter the device account and password for your device.

Device account :

1

Password :

\*\*\*\*\*

Add

Cancel

### 3.3.3 Manual add via UID

You can add the camera use manual add via UID also. Click the Manual add first, then follow below steps:

Add Device

Device type :
☒ All
☐ IPC
☐ NVR

Refresh

Name	Device type	IP	Port	MAC
Foscam_Camera	IPC	192.168.1.246	88	A0EE6F154E85

+ Connect the camera to WIFI

1 device(s)

Add

Cancel

Manual add

**Step 1** Select the UID from Connection mode

**Step 2** Enter the UID of the device.

**Step 3** Click Add

Add Device

Connection mode :

☒ UID

☐ DDNS
Port :

☐ IP address
Port :

Add

Cancel

LAN add

**Step 4** Enter the username and password of the camera.

Device account ✕

Please enter the device account and password for your device.

Device account :

Password :

Add
Cancel

### 3.3.4 Connect the camera to WiFi

You can add the camera via Connect the camera to WiFi also. Click Connect the camera to Wi-Fi or the + button first, then follow below steps:

Add Device ✕

Device type : ☒ All
☐ IPC
☐ NVR
↻ Refresh

Name	Device type	IP	Port	MAC
Foscam_Camera <span style="color: green; font-weight: bold;">✔</span>	IPC	192.168.1.246	88	A0EE6F154E85

+ Connect the camera to WIFI

?

1 device(s)

Add
Cancel
Manual add

**Step 1** Enter the **WiFi Name** and **WiFi Password**, then click **Next**

**Note:** Please reset your camera.

Connect wireless camera to WiFi



Please reset your camera and input the WiFi informations

WiFi Name : FOSCAM

WiFi Password : \*\*\*\*\*

Next

**Step 2** Please scan the QR code above with the camera you want to add. After the scan is successful, click confirm.

Connect wireless camera to WiFi



Please scan the QR code above with the camera you want to add. After the scan is successful, return to the device list to connect the device.

Back

Confirm

**Step 3** Return to the device list to connect the device, refer to the **LAN add steps**

### 3.3.5 Manually Add via DDNS

You can add the camera use manual add via DDNS also. Click the Manual add first, then follow below steps:

Add Device

Device type :
☒ All
☐ IPC
☐ NVR

Refresh

Name	Device type	IP	Port	MAC
Foscam_Camera	IPC	192.168.1.246	88	A0EE6F154E85

+ Connect the camera to WIFI

1 device(s)

Add

Cancel

Manual add

**Step 1** Select the DDNS from the Connection Mode

**Step 2** Enter the DDNS and Port of the camera.

**Step 3** Select "IPC" or "NVR" from the Device types.

**Step 4** Click Add

Add Device

Connection mode :

☐ UID

☒ DDNS

http://

Port :

☐ IP address

Device type :

☒ IPC
☐ NVR

Add

Cancel

LAN add

**Step 5** Enter the username and password of the camera.



Device account

Please enter the device account and password for your device.

Device account :

1


Password :

\*\*\*\*\*

Add

Cancel

## 3.4 Surveillance Software GUI



First time you login the software, the whole video window is gray, you need to connect the cameras and add

cameras to it.

## Section1 Menu Bar



Path to surveillance window. Click this button enter to Device List and back to the surveillance window.



Playback the video recording, you can choose playback type and play video on local or SD card.



Add Device, please refer chapter 3.4 for the detail setting.




More, You can Setting Personal Account, Preference, Left Bar and Switch Account.

## Section2 Left Bar

Add Group: Click the **+ Add Group** button, you can group the device list according to your needs.

**Left Bar of Live:** You can view the list of connected cameras




### 1-----Reconnect

Click the settings button and the device will reconnect.

### 2----- Move To

Click this button, you can move the device to your group list.



### 3-----SD Card

If you have an SD card on your device, click this button to enter the SD directory.


#### 4-----Delete

Click the button, Delete the device.

#### 5----- Setup

Click the button Settings, goes to **Device Settings** Control Panel to make advanced camera settings.

### Section3 Live Window



#### 1-----Close


Click the icon to close this channel live window

#### 2-----Device Name


Show view channel and camera name.

#### 3-----Recording and Alarm status

 This icon will turn to red, it indicates that the camera is recording

 This icon will turn to yellow, the motion is detected during the detection time in the detection area, the camera alarm and adopt the corresponding alarm indicators


#### 4----- Record / Snap Shot / Sound / Talk button



Record Snap Shot Sound Talk

**Record** ----- Click it and do manually recording. When recording, icon 1 will turn to blue. Click it again and stop recording. The recording files will be stored to C disk automatically

**Snap Shot** ----- Click it to make snapshot. After snapshot, the button banner will prompt **Captured Successfully**. And you can find the picture on default path C:\VMS\_CAPTURE



**Sound** ----- Click the icon then you will hear sound captured by the camera's built-in microphone. You may need to plug in earphones or enable the computer speakers to hear from the camera's microphone. Make sure the camera supports audio. Click again and stop audio.

**Talk** ----- Click the button, then talk to the microphone that connected with PC, people around the camera can here you voice. Click the icon again and stop talking.

#### Section4 The number of split-screen



Click this button to select the number of split-screen on one page.




The client can monitor many cameras at one page, here you can choose the display number. The maximum number is 16.

#### Section5 Live Cruise / Close All / Full Screen / Hide Bar



**Live Cruise** ----- Click this button to Live Cruise, you can click  button to add a loop page for live Cruise or click  button to reduce the loop page for live Cruise.



**Close All** ----- Click this button to close all the cameras



**Full Screen** ----- Click this button to enter full screen, Click this button to enter full screen, then click to exit full screen.



**Hide Bar** ----- Click this button, Hide and show Pan / Tilt control Bar

#### Section6 Display / Night Vision

**Display:** You can set HDR and Mirror.

Display :

☒ HDR

☐ Mirror

**Night Vision:** You can set Night Vision.

Night Vision :

- ☒ Auto  
☐ On  
☐ Off  
☐ Schedule


## 3.5 Advanced Camera Settings

Click  the button, goes to Device Settings to make advanced camera settings.

### 3.5.1 Status

Status contains two columns: Device Information and Logs, it will show you various information about your camera.

#### 3.5.1.1 Device Information



The screenshot shows a 'Device Settings' window with a sidebar on the left and a main content area on the right. The sidebar has a 'Status' dropdown menu with 'Device Information' selected. Below it are links for 'Device Status', 'User Access Status', and 'Logs'. Further down are expandable sections for 'Basic', 'Network', 'Video', 'Detector', 'Record', and 'System'. The main content area displays the following information:

Device name :	Foscam_camera
System firmware version :	1.17.2.4
Application firmware version :	2.132.2.10
UID :	BWZ97L52QBOSUZ9FZZZZ7Y8M
MAC ID :	00626EEE4E44
Device time :	2020-12-16 17:02:27

A 'Cancel' button is located at the bottom right of the window.

**Device Name:** The Device Name is a unique name that you can give to your device to help you identify it. Click Basic Settings and go to Camera Name panel where you can change your camera name. The default device name is Foscam\_camera.

**System Firmware Version:** Display the System Firmware version of your camera.

**App Firmware Version:** Display the application firmware version of your camera.

**MAC ID:** Display the MAC address of your camera. For example Device ID is 00626EE96E3C, the same MAC ID sticker is found at the bottom of the camera.

**Device Time:** The system time of the device. Click Basic Settings and go to Device Time panel and adjust the time.

### 3.5.1.2 Device Status

On this page you can see device status such as Alarm status, NTP status, IR LED Status and so on.

Device Settings

· Status

Device Information

Device Status

User Access Status

Logs

· Basic

· Network

· Video

· Detector

· Record

· System

Motion alarm status : Enable

Sound alarm status : Disable

Pedestrian alarm status : Disable

Recording status : Recording

DDNS status : Disable

NTP status : Enable

SD card status : SD card

SD card free space : 295.94 MB


SD card total space : 29.52 GB

Wi-Fi status : Not connected

IR LED status : Off

### 3.5.1.3 User Access Status

Session status will display who and which IP is visiting the camera now



### 3.5.1.4 Logs

The log record shows who and which IP address accessed or log out the camera.

No.	Time	User	IP	Log
1	2020-12-16 17:04:27	root	127.0.0.1	Motion Detection
2	2020-12-16 17:04:02	root	127.0.0.1	Motion Detection
3	2020-12-16 17:03:49	root	127.0.0.1	Motion Detection
4	2020-12-16 17:03:03	root	127.0.0.1	Motion Detection
5	2020-12-16 17:02:51	root	127.0.0.1	Motion Detection
6	2020-12-16 17:02:39	root	127.0.0.1	Motion Detection
7	2020-12-16 17:02:21	root	127.0.0.1	Motion Detection
8	2020-12-16 17:02:05	root	127.0.0.1	Motion Detection
9	2020-12-16 17:01:48	root	127.0.0.1	Motion Detection
10	2020-12-16 17:01:38	root	127.0.0.1	Motion Detection
11	2020-12-16 17:01:19	root	127.0.0.1	Motion Detection
12	2020-12-16 17:01:00	root	127.0.0.1	Motion Detection
13	2020-12-16 17:00:50	root	127.0.0.1	Motion Detection
14	2020-12-16 17:00:40	root	127.0.0.1	Motion Detection
15	2020-12-16 17:00:26	root	127.0.0.1	Motion Detection
16	2020-12-16 16:59:35	root	127.0.0.1	Motion Detection
17	2020-12-16 16:59:25	root	127.0.0.1	Motion Detection
18	2020-12-16 16:59:14	root	127.0.0.1	Motion Detection
19				
20				

Total 41 Pages

< 1 >  Go

Click the page number and go to the corresponding page to see more logs


Full in one page number, click go GO button and go to the corresponding page.

## 3.5.2 Basic

This section allows you to configure your Device Name, Time, User Accounts, Status Light and Voice Prompt.

### 3.5.2.1 Camera Name


Default alias is Foscam\_camera. You can define a name for your camera here such as apple. Click Save to save your changes. The alias name cannot contain special characters.



The screenshot shows the 'Device Settings' window with a sidebar on the left containing 'Status', 'Basic', 'Camera Name', 'Device Time', 'User Accounts', 'Status Light', and 'Voice Prompt'. The 'Basic' category is selected, and the 'Camera Name' sub-item is highlighted. The main area shows 'Camera Name' with a text input field containing 'Foscam\_camera'. A note states: 'The maximum length of device name is 20, support English, numbers, letters and symbols: \_ -'. A close button (X) is in the top right corner.

### 3.5.2.2 Device Time

This section allows you to configure the settings of the internal system clock for your camera.



The screenshot shows the 'Device Settings' window with the 'Device Time' sub-item selected in the sidebar. The main area contains the following settings: 'Time zone' set to '(GMT +08:00) Beijing, Singapore, Taipei'; 'Sync with NTP server' checked; 'NTP server' set to 'Auto'; 'Time format' set to '24H'; 'Date format' set to 'YYYY-MM-DD'; 'Use DST' checked; and DST details set to 'From: April, The first, Saturday, 02 : 00' and 'To: October, The last, Sunday, 02 : 00', with 'DST' set to '0 Minute(s)'. 'Save' and 'Cancel' buttons are at the bottom right. A close button (X) is in the top right corner.

**Time Zone:** Select the time zone for your region from the drop down menu.

**Sync with NTP server:** Network Time Protocol will synchronize your camera with an Internet time server. Choose the one that is closest to your camera.



**Use DST:** Select the **use DST** (Daylight Saving Time, to set the clock ahead of the real-time), then set the start time and end time of the DST, select the daylight saving time from the drop-down menu at last. Click **Save** button and submit your settings.

### 3.5.2.3 User Accounts

Here you can create users and set privilege, visitor, operator or administrator. The default administrator user accounts are administrator with a blank password.

No.	UserName	Privilege
1	1	Administrator

☐ Change username ☐ Change password

Username :

Password :

The maximum username length is 20, including numbers, letters and symbols: \_-@\$\*  
Password should be 6-12 numbers, letters, symbols combination, symbols support: ~!@#%^\*()\_+{}:~|<>?`-;'\./

### How to change the password?

Firstly, select the account which you want to change the password, then select **Change password**, enter the old password and the new password, lastly click modify to take effect.

No.	UserName	Privilege
1	1	Administrator

☐ Change username ☒ Change password

Username : 1

Password :

New Password :

Confirm New Password :

The maximum username length is 20, including numbers, letters and symbols: \_-@\$\*  
Password should be 6-12 numbers, letters, symbols combination, symbols support: ~!@#%^\*()\_+{}:~|<>?`-;'\./

### How to change the username?

Select the account which you want to change the username, then select **Change username**, enter the new username and the password, lastly click modify to take effect.

Device Settings ✕

- Status >
- Basic ▾
  - Camera Name
  - Device Time
  - User Accounts
  - Status Light
  - Voice Prompt
- Network >
- Video >
- Detector >
- PTZ
- Record >
- System >

No.	UserName	Privilege
1	1	Administrator

☒ Change username    ☐ Change password

UserName :

New User :

Password :

The maximum username length is 20, including numbers, letters and symbols: \_-@\$\*

Password should be 6-12 numbers, letters, symbols combination, symbols support: ~!@#%^\*()\_+{}|<>?~!@#%^\*()\_+{}|<>?~!@#%^\*()\_+{}|

### 3.5.2.4 Status Light

If you have a power and network status light on your camera, you can turn it on and off with this feature. This camera don't have the status light described above.

Device Settings ✕

- Status >
- Basic ▾
  - Device Name
  - Device Time
  - User Accounts
  - Status Light
  - Voice Prompt
- Network >
- Video >
- Detector >
- Record >
- System >

Status Light : ☒ On    ☐ Off

### 3.5.2.5 Voice Prompt

You can set the voice prompt on the camera to turn on and off if you connect an external audio device.

Device Settings

· Status

>

· Basic

▼

Device Name

Device Time

User Accounts

Status Light

Voice Prompt

· Network

· Video

· Detector

· Record

· System

Voice Prompt :

☒ Yes
☐ No

### 3.5.3 Network

This section will allow you to configure your camera's information.

#### 3.5.3.1 IP

If you want to set a static IP for the camera, please go to **IP** page. Keep the camera in the same subnet of your router or computer.

Device Settings

· Status

>

· Basic

>

· Network

▼

IP

WiFi

DDNS

Port

P2P

FTP

Mail

Obtain IP from DHCP :

☐ Yes
☒ No

IP address :

192.168.1.197

Subnet mask :

255.255.255.0

Gateway :

192.168.1.1

Primary DNS server :

192.168.1.1



Secondary DNS server :

8.8.8.8

It is recommended that you use the subnet mask, gateway and DNS server from your locally attached PC. If you don't know the subnet mask, gateway and DNS server, you can check your computer's local area connection as follows:

**Control Panel--Network Connections--Local Area Connections --Choose Support--Details.**

41



If you don't know the DNS server, you can use the same settings as the Default Gateway.

### 3.5.3.2 WiFi

**Step 1:** Click the Scan button and the camera will detect all wireless networks around the area. It should also display your router in the list.

Device Settings

Status >

Basic >

Network ▾

IP

WiFi

DDNS

Port

P2P

FTP

Mail

Video >

Detector >

Record >

System >

Wireless network :

Scan

No.	SSID		
1	Xiaomi_49AB_5G		
2	Xiaomi_49AB		
3	FOSCAM		
4	zx123456789	WPA/WPA2	<div></div>
5	FOSCAM_5G	WPA2	<div></div>
6	FYCT	WPA/WPA2	<div></div>
7	QL-C1	WPA/WPA2	<div></div>
8	TP-LINK_B19648	None	<div></div>
9	qiyongkun	WPA/WPA2	<div></div>
10	QC7	WPA/WPA2	<div></div>
11	TP-LINK-LIKAIZHOU	WPA/WPA2	<div></div>
12	Evan_test5G	WPA/WPA2	<div></div>
13	Foscam_wzl	WPA/WPA2	<div></div>
14	PN	WPA2	<div></div>
15	foscam_zzy	WPA/WPA2	<div></div>
16	Foscam-test	WPA/WPA2	<div></div>

SSID : Xiaomi\_49AB

Encryption : WPA/WPA2 ▾

Password :

Test : 

Test

To ensure the Wi-Fi switch takes effect, the device will restart.

Save

Cancel

Click the Scan button to search for wireless networks.

**Step 2:** Click the SSID (name of your router) in the list, the corresponding information related to your network, such as the name and the encryption, will be filled into the relevant fields automatically. You will only need to fill in the password of your network. Make sure that the SSID, Encryption and the password you filled in are exactly the same for your router.

43

**Device Settings**

- Status >
- Basic >
- Network >
  - IP
  - WiFi**
  - DDNS
  - Port
  - P2P
  - FTP
  - Mail
- Video >
- Detector >
- Record >
- System >

Wireless network : Scan

No.	SSID	Encryption	Quality
1	Xiaomi_49AB_5G	WPA/WPA2	Full
2	Xiaomi_49AB	WPA/WPA2	Full
3	FOSCAM	WPA2	Full
8	TP-LINK_B19648	None	Full
9	qiyongkun	WPA/WPA2	Full
10	QC7	WPA/WPA2	Full
11	TP-LINK-LIKAIZHOU	WPA/WPA2	Full
12	Evan_test5G	WPA/WPA2	Full
13	Foscam_wzl	WPA/WPA2	Full
14	PN	WPA2	Full
15	foscam_zzy	WPA/WPA2	Full
16	Foscam-test	WPA/WPA2	Full

Encryption : WPA/WPA2

Password : \*\*\*\*\*

Test : Test

Save Cancel

**1** Click the SSID of your router and the relevant information will be filled in the fields automatically.

**2** Enter the password of your router .

**3** Click Test to check if the password is correct or not.

**Step 3:** Please click on the Save button after all settings have been entered and disconnect the network cable. Never shut down the power of the camera until the IP camera is able to connect to the wireless network. The LAN IP address will disappear on the window of Add Device when the camera is configuring a wireless connection. Wait about 1 minute, the camera should obtain a wireless connection, and the LAN IP of the camera will show again on the window of Add Device. The IP address may have changed after the camera receives a wireless connection; we recommend setting a static local IP address if this IP address changes by right clicking the camera in Equipment Search Tool, setting a static IP, and pushing OK . Congratulations! You have set up the wireless connection of the camera successfully.

**NOTE:** If you fail to make a wireless connection, please refer to your seller or contact us directly for assistance.

### 3.5.3.3 DDNS

FOSCAM cameras can use third-party domain names. You can choose the corresponding third-party domain name.

**Device Settings**

- Status >
- Basic >
- Network >
  - IP
  - WiFi
  - DDNS**
  - Port
  - P2P
  - FTP
  - Mail

DDNS : ☒ Yes ☐ No

Third Party DDNS


DDNS server : None

- None
- Oray
- 3322
- no-ip
- DynDns

### 3.5.3.4 Port

This camera supports HTTP Port / HTTPS Port/ ONVIF Port. HTTP Port is used to access the camera remotely.

**HTTP port:** By default, the HTTP is set to 88. Also, they can be assigned with another port number between 1 and 65535. But make sure they can not be conflict with other existing ports like 25, 21.




The screenshot shows the 'Device Settings' window with a sidebar on the left containing 'Status', 'Basic', 'Network', 'IP', 'WiFi', 'DDNS', and 'Port'. The 'Port' option is selected and highlighted in blue. The main area displays 'Http port : 88' and 'Https port : 443' in input fields. Below these fields, a note states 'Valid port range is 1-65533'.

### 3.5.3.5 P2P

Access the camera by smart phone (Android or iOS operating system)

First of all, you need to open the P2P function of the camera at  > **Network** > **P2P**.



The screenshot shows the 'Device Settings' window with a sidebar on the left containing 'Status', 'Basic', 'Network', 'IP', 'WiFi', 'DDNS', 'Port', and 'P2P'. The 'P2P' option is selected and highlighted in blue. The main area displays 'UID : BWZ97L52QBOSUZ9FZZZZ7Y8M' and 'Enable P2P : ☒ Yes ☐ No'.

### 3.5.3.6 FTP

If you want to upload record images to your FTP server, you can set **FTP**.

· Status >

· Basic >

· Network ▾

IP

WiFi

DDNS

Port

P2P

FTP

Mail

· Video >

· Detector >

· Record >

· System >

Device Settings

FTP server : ftp : //192.168.8.150

Example: ftp://192.168.1.103/dir

The maximum length of the address is 127, does not support the character: =&

Port : 21

Mode : ☐ PASV ☒ Port

Username : test1

The maximum length of the user name is 63, support numbers, letters and symbols: \_@\$%&^\*~!<br/>The maximum length of the password is 63, support numbers, letters and symbols: ~!@\$%^\*~!<br/>

Test

Save

Cancel

**FTP server:** If your FTP server is located on the LAN, you can set as Figure a.

If you have an FTP server which you can access on the internet, you can set as Figure b.

**Port:** Default is port 21. If changed, external FTP client program must change the server connection port accordingly.

**Mode:** Here supports two modes: PORT and PASV.

**Username / password:** The FTP account and password.

Click **Save** to take effect.

Click **Test** to see if FTP has been successfully configured.

### 3.5.3.7 Mail Settings

If you want the camera to send emails when motion has been detected, here Mail will need to be configured.

46



**Device Settings**

· Status >

· Basic >

· Network >

IP

WiFi

DDNS

Port

P2P

FTP

**Mail**

· Video >

· Detector >

· Record >

· System >

Enable mail : ☒ Yes ☐ No

Smtp server :   
Example: smtp.sample.com  
Smtp server address supports English, numbers and @\_,-

Smtp port :

Transport layer security :

G-Mail only supports TLS at Port 465 and STARTTLS at Port 587 or 25. Hotmail only supports STARTTLS at Port 587 or 25.

Need authentication :

Smtp account :   
Example: someone@sample.com  
The maximum length of email is 63, support numbers, letters and symbols: @\_.\$\*-

Smtp password :   
The maximum length of the password is 16, including numbers, letters and symbols: ~!@#%^&\*()\_+{}|<>?`-'\./

Mail sender :

Mail recipient 1 :

Example: someone@sample.com

**1----- SMTP Server/ Port /Transport Layer Security** Enter SMTP server for sender. SMTP port is usually set as 25. Some SMTP servers have their own port, such as 587 or 465, and Transport Layer Security usually is None. If you use Gmail, Transport Layer Security must be set to TLS or STARTTLS and SMTP Port must be set to 465 or 25 or 587, which port you choose should be decided by which Transport Layer Security you select.

**2----- SMTP Account/ password** ID account and password of the sender email address


**3----- E-mail Sender** Mailbox for sender must support SMTP

**4----- Receiver** Mailbox for receiver need not support SMTP, you can set 4 receivers

**5----- Save** Click Save to take effect

**6----- Test** Click Test to see if Mail has been successfully configured.

Click **Test** to see if Mail has been successfully configured.



If the test success, you can see the Success behind the Test, at the same time the receivers will receive a test mail.

If the test fails with one of the following errors after clicking Test, verify that the information you entered is correct and again select Test .

- 1) Cannot connect to the server
- 2) Network Error. Please try later
- 3) Server Error
- 4) Incorrect user or password
- 5) The sender is denied by the server. Maybe the server need to authenticate the user, please check it and try again
- 6) The receiver is denied by the server. Maybe because of the anti-spam privacy of the server
- 7) The message is denied by the server. Maybe because of the anti-spam privacy of the server
- 8) The server does not support the authentication mode used by the device.

## 3.5.4 Video

This section allows you to configure Video Encode settings, On screen display, Snapshot and IR LED settings.

### 3.5.4.1 Video Encode

This is main Encode video settings.

Device Settings

· Status >

· Basic >

· Network >

· Video >

Video Encode

On Screen Display

Privacy Zone

Snapshot

IR LED

Color Adjustment

NAA

HDR

· Detector >

· Record >

· System >

Main Stream Video Settings

Stream type : QHD mode

Frame rate : 25

Resolution : 2K

Key frame interval : 50

Bit rate : 1.5M

Rate control mode : VBR

Sub Stream Video Settings

Stream type : HD mode

Frame rate : 11

Resolution : 720P

Key frame interval : 11

Bit rate : 512K

☒ Enhanced night vision definition

Save

Cancel

**Stream type:** There are four types to identify different streams you have set.

**Resolution:** The camera supports multiple types, For example: 2K,3M,1080P, 720P, VGA. The higher the resolution is, the clearer video will become. But the code flux will become larger too, and it will take up more bandwidth. (Different models support different specific types. )

**Bit Rate:** Generally speaking, the larger the bit rate is, the clearer video will become. But the bit rate configuration should combine well with the network bandwidth. When the bandwidth is very narrow, and bit rate is large, that will lead to video can not play well.

**Frame Rate:** Note that a larger frame size takes up more bandwidth. When the video format is 50Hz, the maximum frame rate is 25 fps. When the video format is 60Hz, the maximum frame rate is 30 fps. You should lower frame rate when the bandwidth is limited. Normally, when the frame rate above 15, you can achieve fluently video.

**Key Frame Interval:** The time between last key frame and next key frame. The shorter the duration, the more likely you will get a better video quality, but at the cost of higher network bandwidth consumption.

**Variable Bitrate:** Select the Bit rate type to constant or variable. If select Yes, the camera will change the video bit rate according to the situation, but will not more than the maximum parameter "Bit Rate"; If select **No**, the Bit Rate is unchanged.

### 3.5.4.2 On Screen Display

This page is used to add time stamp and device name on the video.

The screenshot shows a web interface titled "Device Settings" with a close button (X) in the top right corner. On the left is a sidebar menu with categories: Status, Basic, Network, Video, Video Encode, On Screen Display (highlighted in blue), Privacy Zone, Snapshot, IR LED, Color Adjustment, and NAA. The main content area shows settings for "Display timestamp" and "Display device name", both with radio buttons for "Yes" (selected) and "No".


**Display Timestamp:** There are two options: Yes or NO. Select Yes and you can see the system date on the video,

**Display Camera Name:** There are two options: Yes or NO. Select Yes and you can see the device name on the video.


### 3.5.4.3 Privacy

This page is used to set some mask as privacy zone on the video.

**Privacy Zone:** Allow On Screen Display Mask, there are two options, Yes or NO.



Select Yes and draw a mask area on the video, the mask area will be black on the video.





Click Save button and return to the Privacy Zone page, click Save to take effect.  
Back to the surveillance window, you can see the mask area as the following picture.



### 3.5.4.4 Snapshot

On this page you can set the snapshot pictures' image quality and the storage path.

Device Settings ✕

- Status >
- Basic >
- Network >
- Video ▾
- Video Encode
- On Screen Display
- Privacy Zone
- Snapshot
- IR LED
- Color Adjustment
- NAA
- HDR
- Detector >
- Record >
- System >

Manual snap quality : ☐ Low ☒ Medium ☐ High

Pictures save to : ☒ None ☐ SD card ☐ FTP

☒ Enable timing to capture

Capture interval :  (5s-65535s)

Schedule ⏮ ⏭

	All	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Mon.																									
Tues.																									
Wed.																									
Thur.																									
Fri.																									
Sat.																									
Sun.																									

**Manual Snap Quality:** Low, Middle and High. The higher the quality, the picture will be clearer.

**Pictures Save To:** FTP. If you have done FTP and Alarm settings, when alarming, the camera will snap pictures to the FTP automatically. If you select the FTP, you can set the file name which the picture save to.

### Enable Timing to Capture

To enable capture interval, follow the steps below:

**1 Select Enable timing to capture**

**2 Capture interval:** The interval time between two captures.

**3 Select the capture time**

- Capture anytime


Click the black button up the MON, you will see all time range turn red. When something moving in the detection area at anytime, the camera will capture.

- Specify an capture schedule

Click the week day words, the corresponding column will be selected. For example, click TUE, the all column of TUE turns to red, that means during Tuesday whole day, the camera will capture.

- Press the left mouse and drag it on the time boxes, you can select the serial area,

**4 Click Save button to take effect.**



### 3.5.4.5 IR LED

There are three modes to set the IR LED lights.

**Auto:** The default mode is auto. On this mode, IR LED lights will be switched automatically depended on the brightness of enviroment.

**Manual:** On this mode, you can click **On** option to turn on the IR LED lights, and click **Off** option to turn off the IR LED lights.

**Schedule:** On this mode, IR LED lights will be turned off during the setting schedule .You can set the period of time during which the infrared lamp is turned off to prevent your baby from being influenced during sleep. You can also turn off the infrared lamp on the video preview page at any time.

**Device Settings**
✕

- Status >
- Basic >
- Network >
- Video ▾
- Video Encode
- On Screen Display
- Privacy Zone
- Snapshot
- IR LED
- Color Adjustment
- NAA

IR LED mode : ☐ Auto ☐ Manual ☒ Schedule

Turn the IR LED off in below time(s):

<input checked="" type="checkbox"/> Schedule1	08 ▾	:	00 ▾	-	18 ▾	:	00 ▾
<input type="checkbox"/> Schedule2	00 ▾	:	00 ▾	-	00 ▾	:	00 ▾
<input type="checkbox"/> Schedule3	00 ▾	:	00 ▾	-	00 ▾	:	00 ▾

### 3.5.4.6 Color Adjustment

You can adjust the settings to your liking.

**Device Settings**
✕

- Status >
- Basic >
- Network >
- Video ▾
- Video Encode
- On Screen Display
- Privacy Zone
- Snapshot
- IR LED
- Color Adjustment
- NAA

Hue : 

50

Brightness : 

50

Contrast : 

60

Saturation : 

48

Sharpness : 

35

Default

Power frequency : ☐ 50 Hz ☒ 60 Hz ☐ Outdoor mode

Mirror : ☐

### 3.5.4.7 NAA

Enabling NAA(Network Auto-Adaptability) can make IP Camera changing the real-time rate to adapt different network conditions, which can supply better preview experience.

53

Device Settings

Status

Basic

Network

Video

Video Encode

On Screen Display

Privacy Zone

Snapshot

IR LED

Color Adjustment

NAA

NAA : ☒ On ☐ Off

NAA (Network Auto-Adaptability) can make IP Camera changing the real-time rate to adapt different network conditions, which can supply better preview experience.

## 3.5.5 Detector

### 3.5.5.1 Motion Detection

IP Camera supports **Motion Detection Alarm**, when the motion has been detected, it will send emails or upload images to FTP.

Device Settings

Status

Basic

Network

Video

Detector

Motion Detection

Sound Detection

Alarm Linkage

Record

System

Detection switch : ☒ On ☐ Off

Set detection area

Sensitivity :

Low

Medium

High

Trigger interval :

5s

6s

7s

8s

9s

10s

11s

12s

13s

14s

15s

Snap interval :

1s

2s

3s

4s

5s

Action :

☐ Camera sound

☐ PC sound

☒ Send email

☒ Record

☒ Take snapshot

☒ Push message to the Phone

Schedule

All	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Mon.																								
Tues.																								
Wed.																								
Thur.																								
Fri.																								
Sat.																								
Sun.																								

Save

Cancel



To enable motion detection, follow the steps below:

**1 Enable Detection Switch**

**2 Set detection area** You can set the alarm area.

**3 Sensitivity----** It supports three modes: Low, Middle and High. The higher the sensitivity, the camera will be more easily alarmed. Select one motion sensitivity.

**4 Trigger Interval----**The interval time between two motion detections. Here supports 5s/6s/7s/8s/9s/10s/11s/12s/13s/14s/15s. Select one interval time.

**5 Snap Interval----** The interval time between two pictures.

**6 Select the alarm Action**

**There are some alarm indicators:**

**A Camera Sound**

If you select Camera Sound, when the motion has been detected, the people around the Camera will hear beep alarm sound, if the device is connected with the audio output device.

**B PC Sound**

If you select PC Sound, when the motion has been detected, the people around the PC will hear beep alarm sound.

**C Send E-mail**

If you want to receive alarm emails when motion is detected, you must select Send E-mail and set Mail Settings first.

**D Recording**

If you select this checkbox, when the motion has been detected, the camera will recording and load it to the FTP server. Make sure you have set FTP and set FTP as the storage path in Video->Snapshot settings panel

**E Take Snapshot**

If you select this checkbox, when the motion has been detected, the camera will snap the live view window as a still picture and load it to the FTP. Make sure you have set the storage path in **Video > Snapshot Settings** panel.

**F Push message to the phone**

If you select this checkbox, when the motion has been detected, the camera will push the message to the phone which has been connected the camera.

**7 Alarm Schedule**

1. Alarm anytime when motion is detected

Click the black button up the MON, you will see all time range turn red. When something moving in the detection area at anytime, the camera will alarm.




## 2. Specify an alarm schedule

Click the week day words, the corresponding column will be selected. For example, click TUE, the all column of TUE turns to red, that means during Tuesday whole day, when something moving in the detection area, the camera will alarm.



## 3. Press the left mouse and drag it on the time boxes, you can select the serial area,



**8 Click Save button** to take effect. When the motion is detected during the detection time in the detection area, the camera will alarm and adopt the corresponding alarm indicators.

**NOTE:** You must set the detection area and detection schedule, or else there is no alarm anywhere and anytime.

### 3.5.5.2 Sound Detection

When the ambient sound over a certain decibel ,the sound alarm will be triggered.

**Device Settings**

- Status >
- Basic >
- Network >
- Video >
- Detector >
  - Motion Detection
  - Sound Detection**
  - Alarm Linkage
- Record >
- System >

Detection switch : ☒ On ☐ Off **1**

Sensitivity : **2**

Trigger interval : **3**

Snap interval : **4**

Action : ☐ Camera sound ☐ PC sound **5**

☒ Send email ☒ Record

☒ Take snapshot ☒ Push message to the Phone

Schedule **6**

**7** Save Cancel

To enable motion detection, follow the steps below:

#### 1 Enable Detection Switch

**2 Sensitivity**---- It supports three modes: Low, Middle and High. The higher the sensitivity, the camera will be more easily alarmed. Select one motion sensitivity.

**3 Trigger Interval**----The interval time between two motion detections. Here supports 5s/6s/7s/8s/9s/10s/11s/12s/13s/14s/15s. Select one interval time.

**4 Snap Interval**---- The interval time between two pictures.

#### 5 Select the alarm indicators

**There are some alarm indicators:**

#### **A Camera Sound**

If you select Camera Sound, when the sound has been detected, the people around the Camera will hear beep alarm sound, if the device is connected with the audio output device.

#### **B PC Sound**

If you select PC Sound, when the sound has been detected, the people around the PC will hear beep alarm sound.

#### **C Send E-mail**

If you want to receive alarm emails when motion is detected, you must select Send E-mail and set Mail Settings first.

#### **D Recording**

If you select this checkbox, when the sound has been detected, the camera will recording and load it to the FTP server. Make sure you have set FTP and set FTP as the storage path in Video->Snapshot settings panel

#### **E Take Snapshot**

If you select this checkbox, when the sound has been detected, the camera will snap the live view window as a still picture and load it to the FTP. Make sure you have set the storage path in **Video > Snapshot Settings** panel.


#### **F Push message to the phone**

If you select this checkbox, when the sound has been detected, the camera will push the message to the phone which has been connected the camera.

### **6 Alarm Schedule**

4. Alarm anytime when sound is detected

Click the black button up the MON, you will see all time range turn red. When something moving in the detection area at anytime, the camera will alarm.




### 5. Specify an alarm schedule

Click the week day words, the corresponding column will be selected. For example, click TUE, the all column of TUE turns to red, that means during Tuesday whole day, when something sound in the detection area, the camera will alarm.



### 6. Press the left mouse and drag it on the time boxes, you can select the serial area,



**7 Click Save button** to take effect. When the sound is detected during the detection time in the detection area, the camera will alarm and adopt the corresponding alarm indicators.

**NOTE:** You must set the detection area and detection schedule, or else there is no alarm anywhere and anytime.

### 5.3.5.3 Alarm Linkage

After setting an URL, when camera triggers a detection, will call the URL.

**step:**

1. You can fill in the alarm linkage address in the Full URL and click the Generate button, or modify it in the saved information, then click Save.
2. Full URL example: <http://username:password@ip:port/json.htm?command=switchlight>.

Device Settings

· Status >

· Basic >

· Network >

· Video >

· Detector >

Motion Detection

Sound Detection

Alarm Linkage

· Record >

· System >

Full URL :

http://username:password@ip:port/json.htm?command=switchlight

Generate

URL :

http://ip:port/json.htm

Message :

command=switchlight

Username :

username

Password :

\*\*\*\*\*

Notice :  
1. You can fill in the alarm linkage address in the Full Url and click the Generate button, or modify it in the saved information, then click Save.  
2. Full Url example: http://username:password@ip:port/json.htm?command=switchlight.

## 3.5.6 Record

### 3.5.6.1 Storage Management

On this page you can choose Record Storage Path. The record storage path default is SD card.

Device Settings

· Status >

· Basic >

· Network >

· Video >

· Detector >

· Record >

Storage Management

Alarm Recording

Schedule Recording

Record storage path :

No path

SD card

FTP

SD card status :

SD card

SD card free space :

28.8 GB

SD card total space :

29.5 GB

Notice : SD card management is only effective when access the camera in LAN

SD card management

### 3.5.6.2 Alarm Recording

On this page you can configure the Alarm-recording Time, Enable pre-record time and Alarm-Recording time.

· Status >

· Basic >

· Network >

· Video >

· Detector >

· Record >

Storage Management

Alarm Recording

Schedule Recording

Device Settings

Enable Pre-Record :  
☒ Yes ☐ No

Pre-Record time :  
1s 2s

Alarm-Recording time :  
10s 20s 30s 40s 50s 1min 2min 3min 4min 5min

### 3.5.6.3 Schedule Recording

On the page you can configure the schedule record.

**Note:** Schedule Recording only supports SD Card. Schedule Recording can only be enabled after the recording path is set Please set the path in the storage management.

· Status >

· Basic >

· Network >

· Video >

· Detector >

· Record >

Storage Management

Alarm Recording

Schedule Recording

· System >

Device Settings

Enable schedule : ☒ Yes ☐ No

Audio record : ☐ Yes ☒ No

Full strategy : ☒ Cover ☐ Stop

Stream : ☒ Main stream ☐ Sub stream

Schedule

All	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Mon.																								
Tues.																								
Wed.																								
Thur.																								
Fri.																								
Sat.																								
Sun.																								

Save Cancel

Click **Save** button to take effect.

## 3.5.7 System

In this panel, you can back up/restore your camera settings, upgrade the firmware to the latest version, restore the camera to default settings and reboot the device.

### 3.5.7.1 Back-up & Restore

Click Backup to save all the parameters you have set. These parameters will be stored in a bin file for future use.

Click Browse and select the parameters file you have stored, then click Submit to restore the restore the parameters.

Device Settings

· Status >

· Basic >

· Network >

· Video >

· Detector >

· Record >

· System >

Back-up & Restore

System Upgrade

Patch Installation

Factory Reset

Reboot

Backup is used to save your current settings. It is recommended to backup your configuration before modifying or upgrading firmware.

Backup

Settings can be restored by uploading the backup file.

Backup path : 

Browse

Import

Notice :  
1. All current settings will be overwritten when importing a configuration file. The device may not work properly if the wrong configuration file is uploaded.  
2. Do not disturb the update process by turning off the power, otherwise the device may be damaged. The loading process takes about 50 seconds, and the device will reboot automatically.

### 3.5.8.2 System Upgrade

Click **Download the Latest Firmware**, you will see the following screen. And click **Save** to save the firmware on your computer locally.

Device Settings

· Status >

· Basic >

· Network >

· Video >

· Detector >

· Record >

· System >

Back-up & Restore

System Upgrade

Current firmware version : 2.132.2.10

Download the latest firmware

Browse


System Upgrade



Your current firmware version will be displayed on your screen. You may go to the **Status > Device Information** page to check for the latest firmware versions available. Click **Browse**, choose the correct bin file and then click **System upgrade**. Don't shut down the power during upgrade. After upgrading, you can see the upgrade result.


### 3.5.7.3 Patch Installation

Click "**Browse**" to select the correct patch file, and then click "**Install Patch**" to install the patch. Do not turn off the power during it installing. After installing is complete, you will receive a system prompt.



### 3.5.7.4 Factory Reset

Click **Factory Reset** button and all parameters will return to factory settings if selected.



### 3.5.7.5 Reboot

Click **Reboot** to reboot the camera. This is similar to unplugging the power to the camera. You can set Enable periodic maintenance and set Period.

Device Settings

· Status >

· Basic >

· Network >

· Video >

· Detector >

· Record >

· System ▾

Back-up & Restore

System Upgrade

Patch Installation

Factory Reset

Reboot

Clicking this button will reboot the device

Reboot device

Enable Periodic Maintenance :  
☒ Yes ☐ No

Period :  
☒ A week ☐ A month

# 4 Appendix

## 4.1 Frequently Asked Questions

**NOTE:** Any questions you would meet, please check Network connections firstly. Check the working status revealed by the indicators on the network server, hub, and exchange. If abnormal, check the network connections.

### 4.1.1 Unable to connect to router wirelessly

After setup wireless configuration, and input the wireless password correctly, save the settings. Normally, after you disconnect the Ethernet cable, wait for few minutes camera will show up again in Foscam VMS LAN list with a new IP address. That indicates your camera's connected wireless.

If not, please follow below steps to help camera connect wireless.

Step1: Please make sure wireless signal is strong enough to connect with.

- (1) Best to keep the distance between the camera and router in 2~3 meters while setup;
- (2) There's no interference or obstacles from house appliance or walls;

Step2: Please check if your wireless password contains special characters.

Remove special character in SSID and wireless password to have a try.

Step 3: Reboot camera and router to have a check.

If above are all confirmed, power off and on the camera and router may help camera to connect.

Step 4: Please log-in the router and check if the MAC filter feature is enabled.

Camera has wired and wireless MAC, they are different. If your router has wireless MAC filtering turned on, it'll block camera to connect. Please turn it off, or add camera's MACs in the allow list.

Step 5: Please change the wireless channel, and the wireless encryption of router to have a try.

Change channel helps reduce influence from nearby WiFi networks, you can try 3,6,or 11 for example. As for encryption, suggest use WPA2/PSK AES.

Step6: At last reset camera to default, and please try re-configure the wireless settings again.

### 4.1.2 Forgot camera's user name and password

Camera can be hard reset to default settings, when you forgot camera's login user name and password. Below are the steps:

- (1) Keep power on camera;
- (2) Press and hold reset button of camera for 30 second, till it reboots. Reset button is on bottom, or back, or end cords of the camera.
- (3) Once reset, camera will be restored to default settings. Then re-use Foscam APP or FoscamVMS to add

and set a new user name and password.

### 4.1.3 How to setup alarm recording to Micro SD card

For the cameras that support Micro SD card, we can save alarm recording on SD card and below are the steps to set it up:

Step 1: Setup the Motion Detection Settings

Please go to **Device Settings** > **Detector** > Motion Detection menu.

- (1) Click **ON** for the Detection switch.
- (2) Choose **Recording** for the Action.
- (3) Set the Detection Area
- (4) Set a Schedule.
- (5) Click **Save** to save the settings.

· Status >

· Basic >

· Network >

· Video >

· Detector >

Motion Detection

Sound Detection

Alarm Linkage

· Record >

· System >

Device Settings

Detection switch : ☒ On ☐ Off

Set detection area

Sensitivity :  
Low Medium High

Trigger interval :  
5s 6s 7s 8s 9s 10s 11s 12s 13s 14s 15s

Snap interval :  
1s 2s 3s 4s 5s

Action : ☐ Camera sound ☐ PC sound


☒ Send email ☒ Record

☒ Take snapshot ☒ Push message to the Phone

Schedule

All	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Mon.																								
Tues.																								
Wed.																								
Thur.																								
Fri.																								
Sat.																								

Save Cancel



Note:

- 1) Please DO NOT forget to set the alarm schedule, the alarm schedule is red.
- 2) Please make sure your camera time is correct.
- 3) Please DO NOT forget to set the alarm area, the detected area is covered by the red grids. Or for some models you can setup 3 detection zones in total.

Step 2: Setup the Storage Location

Go to **Device Settings > Record > Storage Location**, and set the "Recording Location" to "SD card" and click **Save**.

Device Settings

×

· Status >

· Basic >

· Network >

· Video >

· Detector >

· PTZ >

· Record >

Storage Management

Alarm Recording

Schedule Recording

· System >

Record storage path : ☐ No path ☒ SD card ☐ Ftp

SD card status : No SD card

SD card free space : 0 KB

SD card total space : 0 KB

Notice : SD card management is only effective when access the Camera in LAN

Save

Cancel

Note:

SD card needs format correctly so it'll be identified by camera, and has enough space for saving the recordings. It's suggested to use FAT32 for 4G~128G SD card.

#### 4.1.4 Unable to connect camera remotely using Foscam app

Foscam P2P cameras allow users to connect camera remotely using Foscam app without extract setup like port forwarding. When it unable to connect remotely, below tips can help app establish the connection:

- (1) Update app and camera's firmware to latest version,
- (2) Power off the camera then power back on,
- (3) Delete camera from app then re-add it back, also lower camera's resolution.

#### 4.1.5 Camera is added by others

When use Foscam app, one camera can only be added to one account at the same time. To solve error "This camera has already been added by another account" when add camera to Foscam app , please reset the camera.

More FAQs are available here:

<https://www.foscam.com/faqs/index.html>

## 4.2 Default Parameters

### Default network parameters

IP address: obtain dynamically

Subnet mask: obtain dynamically

Gateway: obtain dynamically

## 4.3 Specification

ITEMS		Foscam Video Doorbell
Image Sensor	Sensor	High Definition Color CMOS Sensor
	Display Resolution	2688*1520 (4.0M Pixels)
	Min. Illumination	N/A (Without IR Illuminator)
Lens	Lens Type	Glass Lens
	focal length	1.9mm
	Aperture	F 2.0
	Angle of view	Diagonal:170°,Horizontal:152°,Vertical:81°
Video	Image Compression	H.265
	Image Frame Rate	Max 25fps (2K)
	Resolution	2K(2560x1440),1080P(1920x1080),720P(1280 x 720)
	Stream	Dual stream
	HDR	Support HDR
	Flip image	Flip and mirror
	Infrared mode	2pcs SMD IR-LEDs
	Night mode	Manual and automatic modes
	Night visibility	5 m
Audio	Input/Output	Build-in mic and speaker,support full duplex real-time 2-way Audio
	Audio Compression	AAC
Network	Ethernet	Transfer via Type C to RJ45
	Wireless Standard	2.4GHz&5GHz,IEEE802.11b/g/n/ac
	Wireless Security	WPA, WPA2
	Remote Access	P2P
	Wifi configuration mode	Support scan QR code , sound wave to add camera
	Network Protocol	IP、TCP、UDP、SMTP、FTP、DHCP、RTSP、ONVIF
Software Features	Motion Detection	Alarm via E-Mail, upload alarm snapshot to FTP , push message to mobile phone and push stream to Cloud

	Sound Detection	Alarm via E-Mail, upload alarm snapshot to FTP , push message to mobile phone and push stream to Cloud
	Face Detection	Alarm via E-Mail, upload alarm snapshot to FTP , push message to mobile phone and push stream to Cloud
	Face Recognition	Support up to 20 family members
	Privacy Block	Yes
	User Accounts	Three levels user role
	Firewall	Supports IP Filtering
	Custom ringtones	Support to customize exclusive ringtones through mobile APP
	Micro SD card	Support maximum 128GB Micro SD card storage
	Foscam NVR	Compatible with Foscam NVR
	Foscam VMS	Compatible with Foscam VMS
	Visitors leave a message	Support the push of guest messages to the APP
	Reset	Reset button is available
<b>Power</b>	Power Supply	AC8~24V/USB C 5V/ DC12~30V
	Power Consumption	8 Watts (Max.)
<b>Physical</b>	Dimension(LxWxH)	115(L)x45 (W)x25 (H) mm
	Net Weight	125g
<b>Accessories</b>	Power Kit	1pcs(work with existing electronic chime )
	Leveler	1pcs(Pre-install the Leveler on the mounting plate)
	Mounting bracket	Flat Mounting Plate*2pcs,Horizontal Wedge*1pcs,Vertical Wedge*1pcs
	Connector	U-type Connector*1pcs,Fork Connector*1pcs
	Doorbell Wire Extenders and Nuts	With 1pcs extra screw for backup (for AC power of Doorbell), pre-install 2 Wire Extenders on the Doorbell bod
	L-shape Screwdriver	1pcs
	Screws	Wall Mount Screws*1sets,Anti-theft Screws*2pcs
<b>Environment</b>	Waterproof	IP65
	Operating Temperature	-20°C~ 60°C (-4°F ~ 122°F)
	Operating Humidity	20% ~ 85% non-condensing
	Storage Temperature	-20°C ~ 60°C (-4°F ~ 140°F)
	Storage Humidity	0% ~ 90% non-condensing
<b>Certification</b>	CE, FCC, RoHS,WEEE	

## 4.4 CE & FCC

### Electromagnetic Compatibility (EMC)



## FCC Statement



### FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### CE Mark Warning



This is a Class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

## 4.5 WARRANTY

FOSCAM values your business and always attempts to provide you the very best of service.

No limited hardware warranty is provided by FOSCAM unless your FOSCAM product ("product") was purchased from an authorized distributor or authorized reseller. Distributors may sell products to resellers who then sell products to end users. No warranty service is provided unless the product is returned to an authorized return center in the region where the product was first shipped by FOSCAM or to the point-of-purchase, which may have regional specific warranty implications.

**If you purchase your FOSCAM product from online store, please contact the point-of-purchase and ask for return / replacement / repair service.**

### **Limited Hardware Warranty**

FOSCAM products are warranted to be free from manufacturing defects in materials and workmanship starting from the shipping date of FOSCAM.

This limited hardware warranty does not cover:

- Software, including the software added to the products through our factory-integration system, software, etc.
- Usage that is not in accordance with product instructions.
- Failure to follow the product instructions.
- Normal wear and tear.

### **Return Procedures**

- Please read FOSCAM warranty policy & policy of your reseller first before sending items back to point-of-purchase.
- Customer must first contact point-of-purchase to obtain a Return Merchandise Authorization (RMA) number before returning the product. If the product you received is suspected to be defective and the product warranty has not expired, The RMA number will allow your reseller to track your return much easier and help them expedite processing your request.
- After receiving your RMA case number, pack the item(s) very well with the original box and all the original accessories included such as power adapters, brackets, cables, manuals.
- Write your RMA number and the return reason (the problem of the product) on the warranty card along with the complete package to send them back.

### **Replacement Services**

- **If customers ask for replacement service, please contact point-of-purchase and follow their policy.**
- Our technicians will inspect all items returned for replacement requests. If the returned product is found in working order, we will return the same item received. However customers shall be responsible for all shipping & handling charges incurred for getting the units back to customers.
- If returned products are found defective, we will replace the product and assume the shipping cost for sending back the replacement unit to customers.
- If for any reason, we are unable to provide a replacement of the original returned item(s). You will have a choice for a "Substitute" item at the same equal value.
- We do not provide exchange and replacement due to normal hardware upgrade according the market after 14 days after the product is delivered.
- Our technicians will test the product before send out the replacement, any other demand for more than two times replacement for the same product during replacement limit will be rejected.
- **Replaced products are warranted from the balance of the former warranty period.**

### **Warranty Forfeiture**

- Warranty is void if purchase from unauthorized distributor or reseller.
- **Warranty is void if trade-mark, serial tags, product stickers have been removed, altered or tampered with.**
- Warranty is void for mishandling, improper use, or defacing the product.
- Warranty is void for physical damage, altered, either internally or externally, improper or inadequate packaging when returned for RMA purposes.
- Warranty is void if damage has resulted from accident, dismantle, abuse, or service or modification by someone other than the appointed vendor, source, fission or the spare part has been over the period of

warranty.

- Warranty is void if product is damaged due to improper working environment or operation. (For example, improper temperature, humidity, unusual physical or electrical stress or interference, failure or fluctuation of electrical power, static electricity, using wrong power adapter, etc.)
- Warranty is void if damaged by the use of parts not manufactured or sold by FOSCAM.
- Damage caused by improper installation of third-party products.
- Warranty is void if damaged for irresistible cause, such as earthquake, fire, lightning, flood, etc.
- Product beyond limited warranty.

### **Shipping Fee**

- If products are defective or damaged under normal use or operation in the replacement limit, distributors or resellers are responsible for the shipping cost the product back to customers, customers should assume the shipping cost send the product to the point-of-purchase.
- During replacement limit, if customers ask for replacement due to the product does not fit for customer's personal expectation, customers should responsible for both shipping fee.
- Customers shall be responsible for both shipping fee if their product beyond the replacement limit but still in warranty limit.

### **Repair Service Out Of Warranty**

- FOSCAM provide extra repair service for product that out of warranty, it is chargeable. The total fee contains device cost and service fee. Device cost (including accessories) is the standard uniform price provide by FOSCAM.
- Different region may have different service fee, please contact the point-of-purchase to confirm that before you ask for this service.
- Our technicians will quote the total price after detect the product, If customers refused to repair after the quotation, customers need pay for the test fee, \$3.5 / hour. If agree with the quotation, test will be free.
- Repaired product out of warranty will obtains 3-month warranty from the date of the product back to customers.

### **Limitation of Liability**

- FOSCAM is not responsible for other extra warranty or commitment promised by resellers, if your reseller promised some extra commitment or warranty; please ask for written documents to protect your rights and interests.
- FOSCAM does not offer refunds under any circumstances. Please contact the point-of-purchase and follow their refund / return policy.
- FOSCAM shall not be liable under any circumstances for any consequential, incidental, special or exemplary damages arising out of or in any connection with this agreement or the products, including but not limited to lost profits, or any claim based on indemnity or contribution, or the failure of any limited or exclusive remedy to achieve its essential purpose or otherwise. Purchaser's exclusive remedy, as against FOSCAM, shall be the repair or replacement of defective parts. If FOSCAM lists a product on its website specification in error or that is no longer available for any reason, FOSCAM reserves the right to explain it without incurring any liability.

**All rights reserved. FOSCAM and the FOSCAM logo are trademarks of ShenZhen FOSCAM Intelligent Technology Limited., registered in the U.S. and other countries.**

## 4.6 Statement

You are advised to be cautious in daily life, keep personal account information carefully, do not share personal account easily. Change passwords of your account and equipment periodically, and upgrade equipment firmware to strengthen security consciousness.

Our company makes no warranty, implied or otherwise, that this product is suitable for any particular purpose or use. You need to abide by the relevant laws and regulations of the use restrictions when using Foscam cameras. Our company takes no responsibility of illegal activities by using our products.

Our company takes no responsibility of the loss by force majeure, such as failure or faults of telecom system or the Internet network, computer viruses, malicious attacks of hackers, information damage or loss, and faults of computer system.

Foscam company does not need to take any responsibility of the special, incidental or corresponding loss by the products of our company or any software provide by our company, including but not limited to operating loss, profit or purpose. The company only takes the responsibility applicable to national and local legal requirements.

Our company takes no responsibility of the loss caused by the following at any time:

- 1) loss of purchases;
- 2) loss of intangible property damage, such as data, programs;
- 3) loss of compensation claimed by third-party customers.

Delete images, format the memory card or other data storage devices does not completely remove the original image data. You can restore deleted files from discarded the storage device by commercial software, but which will potentially lead to personal image data used maliciously by others. The privacy of the data security belongs to user responsibility, the company takes no responsibility.

Parts mentioned in this statement should not be understood by the configuration description of the product purchased by the customer, the product configuration must accord to the specific models purchased by the customer.

Without the prior written permission of Foscam company, all the contents of relevant operating instructions manual affiliated to the product must not be reproduced, transmitted, transcribed or stored in a retrieval system, or translated into other languages.

Our company will reserve the right to improve and modify the product and corresponding manuals. The company reserves the right of final interpretation on our products.

## 5 Obtaining Technical Support

While we hope your experience with the IP camera network camera is enjoyable and easy to use, you may experience some issues or have questions that this User's Guide has not answered.

If you have problem with FOSCAM IP camera, please first contact FOSCAM reseller for solving the problems.

If our reseller cannot provide service, please contact our service department:

[support@foscam.com](mailto:support@foscam.com)



CE Certificate statement Website: <https://www.foscam.com/company/ce-certificate.html>

Exporter and Importer Information Opened to Public: <https://www.foscam.com/company/open-information.html>

*Manufacturer: Shenzhen Foscam Intelligent Technology Co., Ltd*

*Addr: Room 901-902, Building 1B, Xingke 1st Street, Shenzhen International Innovation Valley, Nanshan Dist., Shenzhen, 518055, China*