

Quick Installation Guide



Model: FN3108XE-B4-1T / FN3108XE-B8-2T

V1.1
EQ310802
- 1 -

1 Security Warning

Foscam cameras and NVRs require good security practices to safeguard your privacy. You can help protect your camera or NVR by changing the default username and/or password.

You should update your camera or NVR regularly at <http://www.foscam.us/firmware.html>. Make sure your camera or NVR has the latest firmware installed for your specific model.



2 Package Contents

8-CH NVR Hard Drive (FN3108XE)	
720P Bullet IP Camera (FI9800XE)	Screw Pack
25M (82 ft) Ethernet Cable	1.8M (5.9 ft) HD Cable
15M (50 ft) Ethernet Cable	USB Mouse
1.5M (5 ft) Ethernet Cable	Power Adapter for NVR
Quick Installation Guide	Quick Operation Guide
Security Warning Card	CD

- 2 -

3 Installing the Cameras

Fixate the camera on your preferred location and use screws to mount it. We have provided screws in the package.




Please Note:

Ensure that the rain or water will not reach the connector ports at the end of the pig tail wiring. These connectors are not weather-resistant.

- 3 -

4 NVR Structure



VGA Output : Connect to your TV or computer monitor with VGA port.

Ethernet Port :10 / 100Mb. You can connect your NVR to the internet via the Ethernet cable.

IP Cameras Input : These ports are for both power and video and are where you plug in your camera cables.

Power Switch : Power on/off button.

Reset : Press and hold the "Reset" button for a while with the NVR powered on, and then release.

The NVR will automatically reboot and restore factory settings. The username and password will be set to the default value "admin/(blank)".

HD-OUT : Connect to your HDTV or computer monitor with HD-OUT port.

USB - USB 2.0 Port. For connecting your USB mouse to control the NVR.

Power Input - This is where you connect the NVR's DC power supply.


- 4 -

5 Device Connection

Step One - Connect Monitor

A: Connect the NVR to your HDTV

Just plug one end in to the HD-OUT socket on the rear of the NVR and the other in to a spare HD-OUT port on your TV.



Note:

If you have already connected your NVR using HD-OUT you don't need to do it again using the VGA port.

B: Connect the NVR to a Monitor or TV

Use the VGA cable that came with your monitor to connect it to the NVR's VGA port.




- 5 -

Step Two - Connect your cameras


To connect your cameras to the NVR simply connect the supplied cable in to the socket of the small cable coming from the camera then plug the other end of this cable into one of the ports on the back of the NVR.

There is a one-to-one relationship between the IP Camera Input port and the video channel of your NVR.



Step Three - Connect to your network

To connect your NVR to the router using Ethernet cable. Please make sure your router has been connected to the internet.



- 6 -

Step Four - Connect the mouse

The USB mouse supplied with your NVR can be connected to either of the two rear USB ports.



Step Five - Connect the power adapter

Connect the power adapter to the power input port.



The connection are now complete. You can turn on the power switch to enter your NVR.

- 7 -

6 Technical Support

If you have problems with your Foscam device, please contact the Foscam reseller you purchased from, or you can e-mail the Foscam headquarter technical support team:

tech@foscam.com.

Your valuable comments and suggestions on improving Foscam products are welcomed!

- 8 -

