



User Manual

Wireless HD Baby Monitor



FosBaby



FosBaby P1

Table of Contents

Security Warning.....	1
1 Overview.....	1
1.1 Key Features.....	1
1.2 Read Before Use.....	2
1.3 Package Contents.....	2
1.4 Physical Description.....	2
1.5 Micro-SD Card.....	4
1.6 Hardware Installation.....	5
2 Access the Camera.....	6
2.1 Access the Camera in LAN.....	6
2.2 Access the FosBaby in WLAN.....	11
2.3 Using the VLC player.....	15
2.4 Camera Connection to the Server.....	17
2.5 CMS Client Monitor.....	17
3 Surveillance Software GUI.....	18
3.1 Login Window.....	18
3.2 Surveillance Window.....	19
4 Advanced Settings.....	26
4.1 Setup Wizard.....	26
4.2 Status.....	26
4.3 Basic Settings.....	28
4.4 Network.....	37
4.5 Video.....	50
4.6 Detector.....	53
4.7 Record.....	60
4.8 Lullabies.....	64
4.9 PTZ (For FosBaby P1).....	65
4.10 Firewall.....	70
4.11 System.....	71
5 Playback.....	74
6 Appendix.....	76
6.1 Frequently Asked Questions.....	76
6.2 Default Parameters.....	83
6.3 Specifications.....	84
6.4 CE & FCC.....	87
6.5 Warranty.....	88
6.6 Statement.....	90
7 Obtaining Technical Support.....	92

Security Warning

Foscam cameras and NVRs require good security practices to safeguard your privacy. You should regularly change your camera or NVR password which is 8-10 numbers, letters, symbols combination. You should update your camera or NVR regularly. Make sure your camera or NVR has the latest firmware installed for your specific model and better experience.

1 Overview

HD Wireless Baby Monitor is an integrated wireless camera with a color CMOS sensor enabling viewing in High Definition resolution. It combines a high quality digital video camera, with a powerful web server, to bring clear video to your desktop and mobile devices from anywhere on your local network or over the Internet.

It supports P2P function. Thanks to the P2P easy access technology, you don't need to do complicated Port Forwarding and DDNS settings, you just need to scan the QR code on the side of the camera to connect it on smart phone, or input the UID on CMS software to realize remote access.

The camera supports H.264 video compression technology, dramatically reducing file size and saving network bandwidth.

The camera is based on the TCP/IP standard. There is a WEB server inside which could support Internet Explorer. Therefore the management and maintenance of your device is simplified by using the network to access the website of your camera.

This model is specially designed for your baby. It is applicable to the baby's room. Besides, Foscam provides a mobile phone App for real-time monitoring, enabling you to see your baby anytime and anywhere. Please search and install Foscam App named **Foscam** on App Store and Google Play for iOS and Android devices, then you can view your camera anywhere, anytime on your smart mobile devices.

1.1 Key Features

- Standard H.264 video compression algorithm to satisfy the transmission of high definition video in narrow bandwidth network
- P2P feature for easy access
- 1 Megapixel HD video
- Pan 320 degree, tilt 100 degree (only FosBaby P1)
- Support IE/Firefox/Google/Safari browser
- Support WEP, WPA-PSK and WPA2-PSK Encryption
- Wireless connection is compliant with IEEE 802.11b/g/n WI-FI, up to 150Mbps
- IR Range (FosBaby Range: 5m(16.4ft); FosBaby P1 Range: 8m(26.2ft))
- Support image snapshot
- Support dual-stream
- Support IR-Cut auto switch

- Support two-way audio
- Multi-level users management with password protection
- Providing free Android and iPhone APP for viewing live video Providing free Central Management Software to manage and monitor multiple cameras
- Support record schedule
- Support Playing Lullabies
- Motion, sound, temperature and humidity Detection via FTP and Email
- Support Cloud Service, Remote access your Baby Monitor without port forwarding
- Support EZlink, Link to WiFi network easily
- Supports voice prompt

1.2 Read Before Use


Please first verify that all contents received are complete according to the Package Contents listed below. Before the camera is installed, please carefully read and follow the instructions in the Quick Installation Guide to avoid damage due to faulty assembly and installation. This also ensures the product is used properly as intended.

1.3 Package Contents


● Camera × 1	● Mounting Bracket×1
● Temperature Detection Sensor × 1	● Watch strap × 1
● Power Adapter × 1	● Power Line × 1
● Remote Control (for P1) × 1	● Quick Installation Guide × 1
● Warning Sticker × 1	● Warranty Card × 1

1.4 Physical Description

FosBaby




FosBaby P1



The Information of Wi-Fi Status Light (Blue):	
Wi-Fi Status Light	Description
Off	No Wi-Fi connection
Flashing every 0.1 seconds	Soft AP takes effect
Flashing every 0.2 seconds	EZLink takes effect (default)
Flashing every 0.4 seconds	WPS is connecting
Slow Flash once per second	Wi-Fi connected

The Information of System Status Light (Yellow):	
System Status Light	Description
off	Power outages
Constant	Power ups

Remote Control of FosBaby P1



Note:

If you used snapshot by the remote control, the default storage path of snapshot files are FTP server and SD card.

1.5 Micro-SD Card

This camera supports SD Card and the max size of SD card must be under 32G.


When you plug in the SD card during the camera work process, please reboot the camera again, or else the

SD Card may be cannot work well.


Go to the **Settings→Device Status→Device Status** page, you can see the SD card status.

1.6 Hardware Installation

- Place the Fosbaby directly on a desk (no mounting bracket required)




- Install your Fosbaby on the wall (with the supplied mounting bracket)



- Take advantage of our provided watch strap for easy fastening!
The strap will allow you to fasten your Fosbaby in an otherwise challenging location (i.e. Crib, Wall bracket, etc.).

Please note: The Fosbaby camera should always be fastened out of your child's reach.



2 Access the Camera

2.1 Access the Camera in LAN

There are some ways of wireless connection: EZLink connection, soft AP connection and WPS connection.

- **EZLink connection:** Use the mobile phones or other mobile devices to download APP, then connect the camera and the wireless router via the APP. The procedure of the EZLink connection, please refer to the Quick Installation Guide.
- **Soft AP connection:** Use the mobile device which can search for the wireless network, Then use the web browser to visit <http://192.168.1.1:88> by the mobile device. Follow the Setup Wizard to finish the settings.
- **WPS connection:** WI-FI Protected Set-up, Press and hold the WPS button on your wireless router and your camera within 60 seconds. So that your camera and wireless router connect successfully.

2.1.1 Soft AP Connection

1. Start camera: power on, the indicator light of camera will light on, and a short musical tone indicates that the startup is completed.
2. Press the Soft AP button for 3-5 seconds. The indicator begins to twinkle at very high frequency.
3. Use a terminal which could search the WLAN (desktop, laptop, This part takes laptop as an example.) to search for the AP named "FosBaby_*****" or "FosBaby P1_*****" for connection.



4. After finishing Soft AP connection, use the web browser of the terminal to visit <http://192.168.1.1:88>.



5. Log in the camera (Default username is admin with no password). When log in for the first time, you need

to change the username and password.




The screenshot shows a web browser window with the address bar displaying `http://192.168.1.188/` and the title "IPCam Client". The Foscam logo is at the top. The main content area features a user modification form. A red callout box with the text "Input the **New username**, **New password** and **Confirm the password**." points to the form fields. The form includes a "Username" field with "admin" entered, and three empty fields for "New username", "New password", and "Confirm the password". A "Security Level" dropdown menu is also present. A "Modify" button is at the bottom right of the form.

Username	admin
New username	<input type="text"/>
New password	<input type="password"/>
Security Level	<input type="text"/>
Confirm the password	<input type="password"/>

Modify

6. After logging in for the first time, it will go to "Setup Wizard" automatically. Please set the basic parameters of the camera, such as camera name, camera time, wireless settings (The camera connect to your wireless router: Wireless Network List - enter the password of your wireless router), IP configuration.



The screenshot shows a "Step 1 of 5 - Soft AP Password Settings" form. It has a table-like structure with fields for SSID, Encryption, Password, Security Level, and Confirm the password. The SSID is "FosBaby_0FD787" and Encryption is "WPA/WPA2". The Password, Security Level, and Confirm the password fields are empty and highlighted with a red border. At the bottom, there are "Previous" and "Next" buttons, with the "Next" button highlighted with a red border.

Step 1 of 5 - Soft AP Password Settings	
SSID	FosBaby_0FD787
Encryption	WPA/WPA2
Password	<input type="password"/>
Security Level	<input type="text"/>
Confirm the password	<input type="password"/>

Previous Next

Setup Wizard

Step 2 of 5 - Camera Name

Camera Name

FosBaby

Device Name The maximum length is 20, support Simplified Chinese, English, numbers, letters and symbols _ -

Previous

Next

Setup Wizard

Step 3 of 5 - Camera Time

Time Zone

(GMT +08:00) Beijing, Singapore, Taipei

Sync with NTP server ☐

NTP Server

time.nist.gov

Device Time

2014-5-15

03

: 09

: 29

AM

Sync with PC/Terminal

Date Format

YYYY-MM-DD

Time Format

12-hour

Previous





Next

Setup Wizard

Step 4 of 5 - Wireless Settings

Wireless Network List

Scan

SSID(Network Name)	Encryption	Quality
TP-LINK_21	WPA/WPA2	
TP-LINK_NVR	WPA2	
TP-LINK_C272	Unencrypt	
FOSCAM-docdev	WPA/WPA2	

SSID

FOSCAM-docdev

Encryption

WPA/WPA2

Password

••••••••

The maximum password length is 63, including numbers, letters and symbols

Setup Wizard

Step 5 of 5 - IP Configuration

Obtain IP From DHCP ☒

IP Address	
Subnet Mask	
Gateway	192.168.1.1
Primary DNS Server	211.162.78.1
Secondary DNS Server	211.162.78.2

Notes:

- We recommend you to choose to manually set the IP when you know some knowledge of the network.
- It needs about 1 minute to connect the camera to your router.

7. After completing the setup wizard, you should press the Soft AP button for 3-5 seconds to cancel the Soft AP connection mode, this is located on the back of your camera. The Network light begins to slowly flash (once per second), it indicates that the wireless connection is successful. (Only Fosbaby P1)

8. Please connect your PC to the router which your camera has connected to.



9. Download the "Equipment Search Tool" from office website <http://www.foscam.com>. Please access the website, select "Support > Download Center > Software Tools", then you can find the "Equipment Search Tool", the icon shows as below:




Download the "Equipment Search Tool" to your computer, double click the icon to run, and it should find the camera's IP address automatically.

Equipment Search Tool			
Camera Name	IP Address	Device ID	Type
Anonymous	Http://192.168.1.105:88	00626E55AB1E	IPC

Notes:

If you have multiple cameras and you cannot determine which camera you are going to log in. Please match the "Device MAC address" on the search tool with the MAC address on the label pasted of each camera.

10. Double-click the camera list here, and your default browser will open up to the login page. Input the username and password you has changed. Then, you will see the live video of your baby on the interface.




Now, you could use your camera in LAN.

Note:

64-bit browser is not supported.

2.1.2 WPS (WI-FI Protected Set-up)

Before using WPS wireless connection, you need to:

Make sure that your wireless router has the WPS function, and has been properly connected to the Internet. WPS button on the wireless router is typically located on the front panel or rear panel. TP-LINK router's WPS button is called QSS (Quick Security Setup).



- (1) Press and hold the WPS button of the camera for three seconds. The Wi-Fi Status Light of the camera begins to twinkle at high frequency. (If you can press and hold this button for more than 10s, the camera will reset. After the reset, the settings of the camera are restored to factory defaults.)
- (2) Press and hold the WPS button for three seconds on your wireless router **within 60 seconds**. Then the camera will automatically create a secure wireless connection to your router in about 60 seconds.

2.2 Access the FosBaby in WLAN

First of all, you need to connect the camera to your wireless router.

2.2.1 Static IP Addresses

Users who have static IP addresses do not need to set DDNS service settings for remote access. When you have finished connecting the camera using the IP address and port forwarding, you can access the camera directly from the Internet using the WAN IP address and port number.

How to Obtain the WAN IP address from a public website ?

To obtain your WAN IP address, enter the following URL in your browser: <http://www.whatismyip.com>. The web page at this address will show you the current WAN IP.



Access your Camera from the Internet

You can access the Camera from the Internet (remote access). Enter the WAN IP address and port number in your standard browser. For example, you would enter `http:// 183.37.28.254:85`

NOTE :

Make sure port forwarding is successful. You can do port forwarding two ways.

Login to your router to enable the “UPNP” function. You can then login to the camera as administrator, choose Network, and then choose UPnP to enable UPnP. Make sure that the status of UPnP reads “UPnP Successful” on the Status page.

Do port (HTTP port and Media port) forwarding manually.

If your router has a Virtual Server, it can do port forwarding. Add the camera’s IP and port which you had set earlier to your router’s port forwarding settings.

Note: If you plug the camera into a router, it will have a dynamic IP address and you need to set DDNS service settings to view it remotely.

2.2.2 Remote Access

If you want to access your camera by web browser outside of your LAN, you need to configure following configurations.

1. Choose “Settings” on the top of the camera web page, then go to the “Network > IP Configuration” section on the left side of the screen, then uncheck the Obtain IP DHCP.

IP Configuration

Obtain IP From DHCP ☐

IP Address	192.168.1.100
Subnet Mask	255.255.255.0
Gateway	192.168.1.1
Primary DNS Server	211.162.78.1
Secondary DNS Server	211.162.78.2

IP Address: Set this in the same subnet as your computer, or keep it as default.
Subnet Mask: Keep it as default.
 Gateway and DNS Server: Set it to the IP address of your router.

2. Enable UPnP and DDNS in the camera's settings page. We recommend you to use the DDNS by factory default.

UPnP

Enable UPnP: No

DDNS

Enable DDNS ☒

Manufacturer's DDNS

Manufacturer's DDNS	test09.myfoscarnet.org	Restore DDNS to factory
---------------------	------------------------	-------------------------

Third Party DDNS

DDNS Server	
Domain	

Click Enable DDNS and click Save.
 The content in the Manufacture' s DDNS column is the domain name of your camera.

3. You can see the port of your camera here. If you want to set Remote Access for several cameras on the same network, you will need to change the HTTPS port for each camera.

Port	
HTTP Port	88
HTTPS Port	443
ONVIF Port	888

4. If the UPnP of the router has been enable, you do not need to perform following steps. Otherwise, you need to select one of the following methods to configure port forwarding on your router. For these steps, we will be using the TP-LINK brand wireless router as an example.

- **If there is a UPnP function in your router:**

Choose “Forwarding > UPnP”, make sure that the Current UPnP Status is Enabled.

UPnP						
Current UPnP Status: Enabled Disable						
Current UPnP Settings List						
ID	App Description	External Port	Protocol	Internal Port	IP Address	Status
Refresh						

- **If there is no UPnP function in your router:**

You need to manually add port(HTTPS port) forwarding, refer to the following steps. You need go to the “Forwarding > Virtual Servers” panel for setup.

Virtual Servers						
ID	Service Port	Internal Port	IP Address	Protocol	Status	Modify
Add New... Enable All Disable All Delete All						
<div style="border: 1px solid red; padding: 5px; display: inline-block;">Click Add New.</div> Previous Next						

5. Now you can access your IP camera by https://domain name: HTTPS port via the Internet.

2.3 Using the VLC player

The camera supports RTSP streaming, here you can view the camera by VLC player.

RTSP URL [rtsp:// \[user_name\]:\[password\]@IP:HTTP port number/videostream](rtsp://[user_name]:[password]@IP:HTTP_port_number/videostream)

The part in the square brackets can be omitted.

user name & password: The user name and password to access the camera. This part can be omitted.

IP: WAN or LAN IP address.

Video stream: Three modes are supported: video Main, video Sub and audio. Video Sub is a better choice in bad network condition. If you select audio, you can only hear sound without seeing picture.

For example:

IP: 192.168.1.11

HTTP Port number: 88

User name: admin



Password: 123

Enter either one of the following four URLs in the VLC


- <rtsp://admin:123@192.168.1.11:88/videoMain>
- [rtsp:// @192.168.1.11:88/videoMain](rtsp://@192.168.1.11:88/videoMain)

- rtsp://123@192.168.1.11:88/videoMain
- rtsp://admin@192.168.1.11:88/videoMain

Open the VLC, and go to “Media”--“Open Network Stream” option, then enter the URL in VLC.



Sometimes you may need to enter the user name and password for another time. Click OK and you can see the real-time preview.



If you cannot play the video in the VLC player, please check the port mapping. You can read Quick Installation Guide about how to configure port forwarding.

NOTE:

If you modify the camera's username or password, you had better reboot the camera to apply the new username and password in authentication in the VLC.

2.4 Camera Connection to the Server

Device supports ONVIF 2.2.1 protocol, You can easily access the NVR with ONVIF or server with ONVIF.

2.5 CMS Client Monitor


FOSCAM offers the most comprehensive central management software IP Camera Client, designed for managing all FOSCAM IP surveillance cameras with numerous features.

It supports management or monitoring multiple cameras for monitoring, recording, playback, and alarm management with efficient control.

3 Surveillance Software GUI

Please refer to the Quick Installation Guide if you install the camera at first time. After finishing quick installation, you can take time to learn the operation of the software.

3.1 Login Window



Section1 Enter the Username and password

The default administrator username is admin with no password, please reset the password at first using and prevent unauthorized users login the camera.

Section2 Stream

The camera supports two stream modes: Main stream and sub stream. If you want to access the camera form WLAN, here you can select Main stream. If you want to access the camera from Internet, here we recommend sub stream.

Note: When the network bandwidth is badly you'd better select Sub Stream and the video will be more fluency.

Section3 Select the language

You can select the language you need via click on the language drop down list to switch.

Section4 Login the camera

Click Login button and you will see the Surveillance video.

NOTE:

When setting up your camera for the first time, it will request that you modify the default username and/or password if both are still set to default. Input the new username and password, click "Modify" to complete the modification. You will now use the new username and password to log in to the camera in the future.

Username

New username

New password

Security Level

Confirm the password

Modify

3.2 Surveillance Window



Section 1 Live Video/ Settings/ Playback buttons



: Real-time temperature and humidity display.



: Path to surveillance window. Click this button and back to the surveillance window.



: Path to Administrator Control Panel, Click it, and it will lead to Administrator Control Panel and

do advanced settings.



: Click this button and back to the Playback panel to view the stored audio files stored in the SD Card.

Section 2 Multi-Device Window



The firmware inside the camera supports up to maximum of 9 cameras being monitoring at the same time. You can add other cameras in multi-device setting.

Section 3 Mode/ Stream / Mirror/ Flip buttons

Mode

- 1) 50HZ -----Indoor surveillance (Region: Europe, China)
- 2) 60HZ -----Indoor surveillance (Region: USA, Canada)
- 3) Outdoor-----Outdoor surveillance

Stream

The default stream supports multiple modes, For example: HD Mode/720P/23fps/2M meanings: Stream type / Resolution / Maximum frame rate/ Bit rate.

1) Stream type : It is used to identify the stream type.

2) 720P/ VGA

There are three resolutions, the bigger one is 1280*720P, and the smaller one is VGA (640*480) pixels. The bigger the resolution is , the better of the image quality is. If you are accessing the camera via internet and want to get more fluent video streaming, please select resolution VGA.

3) Maximum frame rate

You should lower frame rate when the bandwidth is limited. Normally, when the frame rate above 15, you can achieve fluently video.

4) Bit rate

Generally speaking, the larger the bit rate is, the clearer video will become. But the bit rate configuration should combine well with the network bandwidth. When the bandwidth is very narrow, and bit rate is large, that will lead to video can not play well.

You can reset the stream type on “**Settings-> Video-> Video Settings**” panel.

After changing, please re-login the camera and you can see the modification.

Section 4 Pan/Tilt Control(Only P1)



1----- Up control button

3----- Left control button

5----- Up-Left control button

7----- Down-Left control button

2----- Down control button,

4----- Right control button,

6----- Up-Right control button

8----- Down-Right control button



Click this button and go to center

Section 5 Cruise / Preset settings(Only P1)

Cruise Settings



The default cruise tracks have two types: Vertical and Horizontal.

Vertical: The camera will rotate from up to down.

Horizontal: The camera will rotate from left to right.



: Start cruise.




: Stop cruise.

If you want to define or change the cruise trace, please go to **Settings** → **PTZ Preset Settings** panel.

How to do cruise?

Firstly: Select one track in the track dropdown list.



Secondly: Click Start cruise button, the camera will cruise following the predefined path.

Thirdly: Click stop button and finish cruising.

Preset settings



IPCam supports 16 preset positions, which is considered enough for DIY home & small business surveillance market

The default preset position is Topmost, Bottom most, Left most, right most, you can add other preset positions.



Add Click this icon to save the position you need the camera to remember




Delete Select one preset position and click this button to delete it.




GO Select one preset position in the preset drop-down list and click Go to make the camera move the preset position

How to do preset position?

Firstly, move the camera and stop at a desired place where you want make preset position.

Secondly, click  button and enter a descriptive name for the preset position. The preset position cannot contain special characters. Then click OK to save it. If you want to reset the preset position, click Cancel.

After that, you can move the camera and stop at another place, and set another preset position. You can do all the 16 preset positions with this method.

If you want to see one preset position you have set, only select the preset position name from the preset drop-down list, and click go  button, the camera will go to the preset position.

Section 6 IR LED Lights



Click Infra led and there are three modes to adjust the infrared led: Auto, Manual and Schedule.


Auto: Select it and the camera will adjust the infra led (on or off) automatically.

Manual: Select it and you can turn on or turn off the infra led manually.


Schedule: Scheduled control. When it is selected, the function of switching on/off the infrared lamp as scheduled is enabled (Settings> Video > IR LED Schedule).





Section 7 Image quality settings






In this page, you can tune Hue, Brightness, Contrast, Saturation, and Sharpness to get higher quality.



Section 8 Lullabies



: You can click this button to adjust the playing mode of songs. Three playing modes are available for selection:  Circular playing of all songs,  In-order playing, and  Circular playing of a single song.

: You can click this button to set the duration before the camera enters the standby state. Four options are available for selection:  Enter the standby state 10 min later,  Enter the standby state 20 min later,  Enter the standby state 30 min later, and  Not enter the standby state.

Section 9 OSD

2014-11-06 03:04:50 PM 28°C 48%
FosBabyP1 Temperature & Humidity Detection

Go to **Detector--Temperature Detection & Humidity Detection** to set Temperature & Humidity Detection

If you have added time and camera name in the video, you can see it in the live window.

Go to **Settings --- Basic settings--- Camera name** panel, and you can change another device name. The default device name is anonymous.

Go to **Settings --- Basic settings--- Camera time** panel and adjust the device time.


Go to **Settings --- Video--- On Screen Display** panel, you can add or no add OSD.


Section 10 Play/Stop/ Talk/Audio/ Snap/ Record/ Full screen button




1----- Play Click it to play the video of the camera


2----- Stop Click it to stop the video of the camera

3----- Talk Click the button and the icon will become to , then talk to the microphone that connected with PC, people around the camera can hear your voice. Click the icon again and stop talking.

4----- Audio Click this icon, the icon will become to , you can hear the sound around the camera by the earphone or speakers that connected with PC.

5----- Play lullabies Click this icon, the icon will become to , camera will play nursery rhymes.

6----- Snapshot Click it to make snapshot and it pop-up a window which picture you snapshot, right click in the window and save the picture to anywhere you want.

7----- Record Click the icon  and the camera start recording, you can see a green dot in the live window. Click again and stop recording. The default storage path is C:\IPC\CamRecord of Windows OS and the default storage path is \IPC\CamRecord of Mac OS. You can change the storage path: Go to Settings->Record->Storage Location panel.

8----- Full Screen Click it to make full-screen, or you can double click the surveillance screen to make full-screen. Double click again and exit full-screen.

Onscreen Mouse Control


Right click the mouse and you can adjust the screen ration, full screen and Zoom up.



Full Screen: Select it and Click it to make full-screen, press ESC and exit full-screen.

Zoom up: Select it and you can see a bigger screen than before.

When you select the Full Screen, then click right mouse, there is a Screen PTZ button.



NOTE: For Mac OS, the plugin cannot support Onscreen Mouse Control, so you cannot allow to use it.

4 Advanced Settings

Click the button “**Settings**”, goes to Administrator Control Panel to make advanced camera settings.


4.1 Setup Wizard

In the Setup Wizard page, you could complete the basic parameters, such as device name, system time, wireless networks, IP address, etc. follow the prompts.

4.2 Status

Status contains four columns: Device Information, Device Status, Session Status and Log, it will show you various information about your camera.

4.2.1 Device Information



The screenshot shows the 'Status' menu on the left with 'Device Information' selected. The main panel displays 'Device Information' with a 'Refresh' button and a table of device details.

Device Information	
Camera Model	FosBaby
Camera Name	FosBaby
Camera ID	008414812610
Camera Time	2014/02/17 05:48:17
System Firmware Version	1.5.1.10
Application Firmware Version	2.22.1.6
Plug-In Version	2.0.2.11

Camera Model: The camera model NO.

Camera Name: The Device Name is a unique name that you can give to your device to help you identify it. Click **Basic Settings** and go to **Camera name** panel where you can change your camera name. The default device name is anonymous.

Camera ID: Display the wired MAC address of your camera. For example Device ID is 000C5D000088, the same MAC ID sticker is found at the bottom of the camera.

Camera Time: The system time of the device. Click **Basic Settings** and go to **Camera time** panel and adjust the time.

System Firmware Version: Display the System Firmware version of your camera.

Application Firmware Version: Display the application firmware version of your camera.

Plug-In Version: Display the plug-in version of your camera

4.2.2 Device Status

On this page you can see device status such as Alarm status/Record Status, DDNS status, WIFI status

and so on.

Device Status	
Refresh	
Alarm Status	Disabled
Record Status	Not Recording
SD Card Status	SD card
SD Card Free Space	1.4GB
SD Card Total Space	3.6GB
NTP Status	Disabled
DDNS Status	Susscess http://test09.myfoscam.org
UPnP Status	Susscess
WiFi Status	Connected to :foscam-wifi
IR LED Status	Off

4.2.3 Session Status

Session status will display who and which IP is visiting the camera now.

Status	Session Status	
Device Information	Refresh	
Device Status		
Session Status	Username	IP Address
Log	admin	192.168.1.101
Basic Settings		

4.2.4 Log

The log record shows who and which IP address accessed or logout the camera.

Pages:83					Refresh
					<<1 2 3>> <input type="text"/> Go
NO.	Time	User	IP	Log	
1	2012-09-18 02:11:45	admin	192.168.1.102	Log out	
2	2012-09-18 01:48:56	admin	192.168.1.102	Log out	
3	2012-09-18 01:29:51	admin	192.168.1.102	Log out	
4	2012-09-18 01:27:54	admin	218.17.160.187	Log out	
5	2012-09-18 01:26:21	admin	192.168.1.100	Log out	
6	2012-09-18 01:25:42	admin	218.17.160.187	Login	
7	2012-09-18 01:25:15	admin	192.168.1.102	Login	
8	2012-09-18 01:25:13	admin	192.168.1.102	Log out	
9	2012-09-18 01:24:46	admin	192.168.1.100	Login	
10	2012-09-18 01:21:44	admin	192.168.1.102	Login	

Reboot the camera and clear the log records.

4.3 Basic Settings

This section allows you to configure your camera's Name, Time, Mail, User account and Multi-Device.

4.3.1 Camera Name

You can define a name for your camera here such as apple. Click Save to save your changes. The alias name cannot contain special characters.

Status
Basic Settings
Camera Name
Camera Time
User Accounts
Multi-Camera
Network

Camera Name

Save
Refresh

Camera Name

FosBaby

The maximum Device Name length is 20, support English, numbers, letters and symbols

4.3.2 Camera Time

This section allows you to configure the settings of the internal system clocks for your camera.

<div>Save</div> <div>Refresh</div>	
Time Zone	(GMT) Greenwich mean time; London, Lisbon, (
Sync with NTP server <input checked="" type="checkbox"/>	
NTP Server	Auto
Device Time	<div>2016-4-26</div> <div>08 15 53</div> <div>Sync with PC/Terminal</div>
Date Format	YYYY-MM-DD
Time Format	24-hour
use DST <input checked="" type="checkbox"/>	
From	April first Sunday 2 : 00
To	October the last one Sunday 2 : 00
Ahead Of Time	0 Minute

Time Zone: Select the time zone for your region from the drop-down list.

Sync with NTP server: Network Time Protocol will synchronize your camera with an Internet time server. Choose the one that is closest to your camera.

Sync with PC: Select this option to synchronize the date and time of the Network Camera with your computer.

Manually: The administrator can enter the date and time manually. Note select the date and time format.


use DST: Select the daylight saving time from the drop-down list.

Click **Save** button and submit your settings.

NOTE: If the power supply of camera is disconnect, you need set the camera's time again.


4.3.3 User Accounts

Here you can create users and set privilege, **visitor**, **operator** or **administrator**. The default user account is admin, with a blank password. You can enter the users accounts of visitor, operator and administrator Manually.



How to change the password?


Firstly, select the account which you want to change the password, then select "Change password", enter the old password and the new password, lastly click modify to take effect.



How to add account ?

Select one blank column, then enter the new user name, password and privilege, last click Add to take effect. You can see the new added account on the Account list.

User Accounts

 Refresh

NO.	Username	Privilege
1	admin0	Administrator
2		
3		
4		
5		
6		
7		
8		

Username:

Password:

Security Level:

Confirm the password:


Privilege: Administrator ▼

☐ Change username

☐ Change password

Add

User Accounts

 Refresh

NO.	Username	Privilege
1	admin0	Administrator
2	test	Visitor
3		
4		
5		
6		
7		
8		

Username:

Privilege: Visitor ▼

☐ Change username

☐ Change password

Delete

Delete : Select the account which you want to delete, then click Delete button to take effect.
NOTE: The default admin account cannot be deleted, but you can add other administrator users.

How to change the username ?

Firstly, select the account which you want to change the username, then select “Change username”, enter the new password, lastly click modify to take effect.

User Accounts

↻ Refresh

NO.	Username	Privilege
1	admin0	Administrator
2	test	Visitor
3		
4		
5		
6		
7		
8		

Username

New username

Privilege

Visitor ▼

☒ Change username

☐ Change password

Modify

4.3.4 Multi-Camera

If you want to view multi-surveillance screens on one window, you need to login one camera, and set it as the main device, and do Multi-Device Settings, add other cameras to the first one camera. Before you do multi-cams settings, you need to assign different port such as 81, 82, 83, 84, 85, 86, 87, 88 to the cameras if there is 8 cams installed.

The firmware within the camera can support a maximum of 9 devices monitoring all at the same time. This page you can both add FOSCAM MJPEG and H.264 series cameras to the first camera and view multi-surveillance screen on one window.

Add cameras in WLAN

In Multi-Device Settings page, you can see all devices searched in WLAN. The 1st Device is the default one. You can add more cameras in the list in WLAN for monitoring. The camera's software supports up to 9 IP Cameras online simultaneously. Click The 2nd Device and click the item in the Device List in WLAN, the Alias, Host and Http Port will be filled in the boxes below automatically. Enter the correct username and password then click Add. Add more cameras in the same way.

Cameras On LAN	FC2401P(172.16.0.195) FI9821W(172.16.0.47) EH8155fx(172.16.2.136) Foscam NVR(172.16.1.67) Foscam NVR(172.16.1.71) Foscam NVR(172.16.1.59) <input type="button" value="Refresh"/>	1.Click it, camera model, alias, host and HTTP Port will be filled in the following boxes automatically.
The 1st Camera	This Camera	
The 2nd Camera	None	
Camera Model	H264	
Camera Name	FI9821W	
Host	172.16.0.47	
HTTP Port	88	
Media Port	88	
Username		
Password		
3.Click Add to take effect.		<input type="button" value="Add"/> <input type="button" value="Delete"/>


Camera Model: Our Company produces two series cameras: MJPEG and H.264. Here will show you which series the camera belongs to.

Cameras On LAN		anonymous(192.168.11.193) FI9821W for ebuyer (192.168.11.241) anonymous(192.168.11.203) anonymous(192.168.11.243) <input type="button" value="Refresh"/>
The 1st Camera	This Camera	
The 2nd Camera	FI9821W(172.16.0.47)	
The 3rd Camera	FI9821W for ebuyer (192.168.11.241)	
The 4th Camera	anonymous(192.168.11.203)	
The 5th Camera	None	
The 6th Camera	None	
The 7th Camera	None	
The 8th Camera	None	
The 9th Camera	None	
Note: If you want to access your camera remotely, make sure you are able to access it seperately through a browser.		

Back to **Surveillance Windows**, and click Four Windows option, you will see four cameras you added.



Using the same method, you could to add other cameras continue. It can add up to 9 road equipment.




Add cameras in WAN

If you want to view all cameras via the internet (remote computer), you will need to add them using DDNS domain name. Firstly, make sure all of the cameras you added can be accessed through the internet.

(Read How to configure DDNS settings)

Login to the first camera using a DDNS domain name and port.



Click **Multi-Device Settings**. Choose **The 2nd Device**. Fill in the 2nd camera's name, DDNS domain name, port number. Enter user name and password and then choose Add.

The 1st Camera	This Camera
The 2nd Camera	FI9821W(172.16.0.47)
Camera Model	H264 1
Camera Name	FI9821W 2
Host	172.16.0.47
HTTP Port	88 3
Media Port	88
Username	admin
Password	4
5 Add Delete	

1----- The camera model: MJ or H264.

2----- The 2nd camera's name

3----- Fill in the 2nd camera's DDNS host not IP

NOTE: The MJ series have the same HTTP Port NO. and Media Port NO.

4 ---- Enter the 2nd camera's user name and password

5---- Click Add button and to take effect

NOTE: Here the Host must be entered as the second camera's DDNS domain name, not its IP.

Refresh

Cameras On LAN	anonymous(192.168.11.193) FI9821W for ebuyer (192.168.11.241) anonymous(192.168.11.203) anonymous(192.168.11.243)	Refresh
The 1st Camera	This Camera	
The 2nd Camera	FI9821W(172.16.0.47)	
The 3rd Camera	FI9821W for ebuyer (192.168.11.241)	
The 4th Camera	anonymous(192.168.11.203)	
The 5th Camera	None	
The 6th Camera	None	
The 7th Camera	None	
The 8th Camera	None	
The 9th Camera	None	

Note: If you want to access your camera remotely, make sure you are able to access it separately through a browser.


Return to video window. You will see all of the cameras accessible through the internet.

When you are away from home, you can use the first camera's DDNS domain name and port to view all the cameras via internet.



4.3.5 Status Light


You can enable or disable the status light.



The screenshot shows the 'Status Light' configuration page. On the left is a sidebar menu with options: Setup Wizard, Status, Basic Settings, Camera Name, Camera Time, User Accounts, Multi-Camera, and Status Light (which is highlighted). The main content area has a title 'Status Light' and two buttons: 'Save' and 'Refresh'. Below the title is a form with a label 'Enable Status Light' and a dropdown menu currently set to 'Yes'.

4.3.6 Night Light (FosBaby P1)

You can turn on / off the night light manually.



The screenshot shows the 'Night Light' configuration page. On the left is a sidebar menu with options: Setup Wizard, Status, Basic Settings, Camera Name, Camera Time, User Accounts, Multi-Camera, Status Light, and Night Light (which is highlighted). The main content area has a title 'Night Light' and two buttons: 'Save' and 'Refresh'. Below the title is a form with a label 'Whether to enable Night Light' and a dropdown menu currently set to 'No'.

4.4 Network

This section will allow you to configure your camera's IP, DDNS, Wireless Settings, UPnP and Port.

4.4.1 IP Configuration

If you want to set a static IP for the camera, please go to **IP Configuration** page. Keep the camera in the same subnet of your router or computer.

IP Configuration


Obtain IP From DHCP ☐


IP Address	192.168.1.102
Subnet Mask	255.255.255.0
Gateway	0.0.0.0
Primary DNS Server	0.0.0.0
Secondary DNS Server	0.0.0.0

Changing settings here is the same as using the Equipment Search Tool .

It is recommended that you use the subnet mask, gateway and DNS server from your locally attached PC. If you don't know the subnet mask, gateway and DNS server, you can check your computer's local area connection as follows:

Control Panel → Network Connections → Local Area Connections → Choose Support → Details





If you don't know the DNS server, you can use the same settings as the Default Gateway.

4.4.2 Wireless Settings

Step 1: Choose “**Settings**” on the top of the camera interface, and go to the “**Network**” panel on the left side of the screen, then click “**Wireless Settings.**”

Click the **Scan** button and the camera will detect all wireless networks around the area. It should also display your router in the list.

Wireless Settings

Save Refresh

Wireless Network List

SSID(Network Name)	Encryption	
MERCURY_9E72A8	Unencrypt	
TP-LINK_B2637A	Unencrypt	
MERCURY_07EA54	WPA/WPA2	📶
dlink-chenchen2.4G	WPA/WPA2	📶
maq	WPA/WPA2	📶
zhwwang_1	WPA/WPA2	📶
TP-LINK_CB209C	Unencrypt	📶
FOSCAM-docdev	WPA/WPA2	📶
TP-LINK_liyo		
WUXIAOCHUAN		

Scan

Click the Scan button to search for wireless networks.

SSID: FOSCAM-docdev

Encryption: WPA/WPA2

password length is 63, including
and symbols ~ ! @ # * () _ { } :

" | < > ? ' - ; ' \ , . /

Pages: 4 << 1 2 3 >> Go

Click the Page number to see other wireless networks devices if there are more than 10.

Step 2: Click the SSID (name of your router) in the list, the corresponding information related to your network, such as the name and the encryption, will be filled into the relevant fields automatically.

You will only need to fill in the password of your network. Make sure that the SSID, Encryption and the password you filled in are exactly the same for your router.

Wireless Settings

Save Refresh

Wireless Network List Scan

SSID(Network Name)	Encryption	Quality
MERCURY_9E72A8	Unencrypt	<div style="width: 20px; height: 10px; background-color: green;"></div>
MERCURY_07EA54	WPA/WPA2	<div style="width: 20px; height: 10px; background-color: green;"></div>
dlink-chenchen2.4G	WPA/WPA2	<div style="width: 20px; height: 10px; background-color: green;"></div>
maqib	WPA/WPA2	<div style="width: 20px; height: 10px; background-color: green;"></div>
FOSCAM-docdev	WPA/WPA2	<div style="width: 20px; height: 10px; background-color: green;"></div>
TP-LINK_liyo	WPA/WPA2	<div style="width: 20px; height: 10px; background-color: green;"></div>
WUXIAOCHUAN	WPA/WPA2	<div style="width: 20px; height: 10px; background-color: green;"></div>
TP-LINK_jingyuan	WPA2	<div style="width: 20px; height: 10px; background-color: green;"></div>
TP-LINK_wyy	WPA/WPA2	<div style="width: 20px; height: 10px; background-color: green;"></div>
D-Link_wly	WPA	<div style="width: 20px; height: 10px; background-color: green;"></div>

SSID: FOSCAM-docdev

Encryption: WPA/WPA2

Password:

2 Enter the password of your router.

1 Click the SSID of your router and the relevant information will be filled in the fields automatically.

Pages: 4 << 1 2 3 >> Go

Step 3: Please click on the **Save** button after all settings have been entered and disconnect the network cable. Never shut down the power of the camera until the camera is able to connect to the wireless network.

The IP address will disappear on the window of Equipment Search Tool when the camera is configuring a wireless connection. Wait about 1 minute, the camera should obtain a wireless connection, and the IP of the camera will show again on the window of the Equipment Search Tool. The IP address may have changed after the camera receives a wireless connection; we recommend setting a static local IP address if this IP address changes by right clicking the camera in Equipment Search Tools, setting a static IP, and pushing OK.

Congratulations! You have set up the wireless connection of the camera successfully.

4.4.3 Soft AP Password Settings

For the safety of your camera, we recommend you change the Soft AP password.

Soft AP Password Settings	
SSID	FosBabyP1_1DA0ED
Encryption	WPA/WPA2
Password	<input type="password"/>
Security Level	
Confirm the password	<input type="password"/>

4.4.4 DDNS

FOSCAM camera has embedded a unique DDNS domain name when producing, and you can directly use the domain name, you can also use the third party domain name.

FOSCAM domain name

Here take **test09.myfoscam.org** for example. Go to option of DDNS on the **Settings->Network** panel, you can see the domain name.

Enable DDNS ☒

Manufacturer's DDNS

Manufacturer's DDNS	<input type="text" value="test09.myfoscam.org"/>	<input type="button" value="Restore DDNS to factory"/>
---------------------	--------------------------------------------------	--------------------------------------------------------

Third Party DDNS

DDNS Server	<input type="text" value="None"/>
Domain	<input type="text"/>

Now you can use **http:// Domain name + HTTP Port** to access the camera via internet.

Take hostname **test09.myfoscam.org** and HTTP Port NO. 800 for example, the accessing link of the camera via internet would be **http:// test09.myfoscam.org:800**

Restore DDNS to factory: If you have configured Third Party DDNS successfully, but you want to use Manufacturer's DDNS again , here click this button and start Manufacturer's DDNS Service.

Third Party Domain Name Settings

User can also use third part DDNS, such as **www.no-ip.com. ,www. 3322.com**

Here take **www.no-ip.com** for example:

① **Step 1, Go to the website www.no-ip.com to create a free hostname**

Firstly: Login on www.no-ip.com and click No-IP Free to register.

Managed DNS Provider
[Sign Up](#)
[Home](#)
[Blog](#)
[Support](#)
[Contact Us](#)
[Sign In](#)

[Services](#)
[Why No-IP?](#)
[Download](#)
[Support](#)

Enhanced Dynamic DNS

more features, flexibility & control

Connect remotely to your computer, DVR, webcam or run your own web server or website on a dynamic IP address.

[What is Dynamic DNS?](#)

[Sign Up Now](#)
Up to 25 Hostnames

Personal Use

Dynamic DNS allows you to monitor your home remotely via webcam, access your computer remotely, or even run your own server all on a dynamic IP address.

- ✓ Remote Access
- ✓ Webcam Monitoring
- ✓ Quick Installation
- ✓ Simple Domain Name

[Get Started](#)

Business Use

Trust our DNS experts with your web domains DNS management. Our Managed DNS will ensure your website is fast, reliable and always available.

- ✓ 100% Uptime Guaranteed
- ✓ Fast Redundant Websites
- ✓ Trusted Anycast Network
- ✓ 11 Points of Presence

[Get Started](#)

No-IP Free

No-IP Free is our entry level service. Use yourname.no-ip.org instead of a hard to remember IP address or URL. With No-IP Dynamic DNS, our free Dynamic Update Client keeps track of your changing IP address and updates your hostname, keeping your connection active.

[Sign Up Now](#)
[More](#)

[Click here to register.](#)

Domain Registration

Fast, simple and affordable Domain Registrations. 100% Uptime Guaranteed!

[Learn More](#)

POP3 / IMAP Email

Easily manage email accounts for your own domain and access your email from anywhere.

[Learn More](#)

SSL Certificates

Ensure your website visitors are safe and secure by purchasing an SSL Certificate.

[Learn More](#)

Please register an account step by step according to instructions on www.no-ip.com

After registration, please login your email which used to register. You will receive an email from website, please click the link to activate your ACCOUNT as indicated in email.

Secondly: Login the link with the registered username and password to create your domain name.

Client Login

Home » [Client Login](#)

Email:

Password:

[Login](#)

[Forget your password? No problem, \[Click Here\]\(#\)](#)

If you are not currently a registered user of No-IP.com, and would like to be for FREE, [register](#) as a new user.

User Login

Username:

Password:

[Create Account](#) [Forgot password?](#) [Login](#)

Additional Services

- No-IP Enhanced**
Upgrade your No-IP account to unlock many exciting features.
- No-IP Backup DNS**
Maximize uptime and add **Anycast** to your existing DNS infrastructure.
- No-IP Monitoring**

Hosts/Redirects | DNS Hosting | Domain Registration | Mail | SSL Certificates | Monitoring | Backup DNS | Renew/Activate

Your No-IP

Cuxiang, welcome to your No-IP! Last Login: 2012-04-04 21:40:56 PDT from IP 65.49.14.58

You have successfully logged into No-IP's member section. To start using No-IP's services select an icon below or choose an item from the navigation above.

[Manage Domains](#) [Add Domain](#) [Refer Friend](#) [Add a Host](#) [Manage Hosts](#)

FROM \$15 Find a Domain Name [Search](#)

Need Help?

- Support Center
- Basic Troubleshooting Guide
- Support Ticket
- Contact Us

Get Connected

[RSS](#) [Facebook](#) [Twitter](#) [YouTube](#)

Own a domain name?

Use your own domain name with our DNS system. [Add](#) your domain name now or [read more](#) for pricing and features

Your No-IP Alerts

You do not have any notices at this time

Check this spot for important information regarding your account such as expiring services and trouble tickets.

[Home](#) | [API](#) | [Contact Us](#) | [Sitemap](#) | [Terms of Service](#) | [Privacy Policy](#) | [Blog](#)

Please create the domain name step by step according to instructions on www.no-ip.com

Step 2, DO DDNS Service Settings within the Camera

Please set DDNS Settings within the camera by host name, a user name and password you've got from

www.no-ip.com

Take host name ycxgwp.no-ip.info, user name **foscam**, password **foscam2012** for example.

Firstly, goes to option of DDNS Settings on the administrator panel.

Secondly, select No-Ip as a server.

Thirdly, fill **foscam** as DDNS user, fill password **foscam2012** as DDNS password, fill ycxgwp.no-ip.info as DDNS domain and server URL, Then click save to make effect. The camera will restart and to take the DDNS settings effective.

Fourthly, after the restart, login the camera, and go to option of Device Status on the administrator panel, and check if the DDNS status is successful.

If failed, please double check if you have input the correct host name, user name, and password, and try to redo the settings.

NOTE :

If you have set Third Party DDNS successfully ,the Foscam Domain Name will be invalid. The Third Party DDNS and the Foscam Domain Name cannot work at the same time, the last time you configured will take effect.

② Do port forwarding within the router

Example: The camera's IP address is http://192.168.8.100:2000 , Media port no. is 9200.

Firstly, login the router, goes to the menu of **Port Forwarding or Port Trigger** (or named Virtue Server on some brands of router). **Take TP-Link brand router as an example, Login the router, and goes to Applications & Gaming->Single Port Forwarding.**

Secondly, Create a new column by IP address & HTTP Port No. of the camera within the router showed as below.

The screenshot shows the 'Single Port Forwarding' configuration page on a TP-Link router. The page has a table with columns: Application Name, External Port, Internal Port, Protocol, To IP Address, and Enabled. There are two rows of configuration. The first row is for HTTP (port 2000) and the second row is for Media (port 9200). Both rows are set to 'Both' protocols and point to the internal IP 192.168.8.100. Red boxes and arrows highlight the configuration fields with the following annotations:

- Assign a name as you like here.** (points to the Application Name dropdown)
- Fill the HTTP Port no. of the camera on the column of External Port and Internal Port.** (points to the External and Internal Port fields for the first row)
- Fill the Media Port no. of the camera on the column of External Port and Internal Port.** (points to the External and Internal Port fields for the second row)
- Fill the LAN IP of the camera here, just input the last section.** (points to the To IP Address field for the second row)


Application Name	External Port	Internal Port	Protocol	To IP Address	Enabled
None	---	---	---	192.168.8.---	<input type="checkbox"/>
None	---	---	---	192.168.8.---	<input type="checkbox"/>
None	---	---	---	192.168.8.---	<input type="checkbox"/>
None	---	---	---	192.168.8.---	<input type="checkbox"/>
Http	2000	2000	Both	192.168.8.100	<input checked="" type="checkbox"/>
Media	9200	9200	Both	192.168.8.100	<input checked="" type="checkbox"/>
---	---	---	---	192.168.8.---	<input type="checkbox"/>

③ Use domain name to access the camera via internet

After the port forwarding is finished, you can use the **domain name+ http no.** to access the camera via

internet. Take hostname **ycxgwp.no-ip.info** and **http NO. 2000** for example, the accessing link of the camera via internet would be **http:// ycxgwp.no-ip.info:2000**

4.4.5 UPnP



The default UPnP status is closed. You can enable UPnP, then the camera's software will be configured for port forwarding. Back to the **"Device Status"** panel, you can see the UPnP status:

Device Status		Refresh
Alarm Status	Disabled	
Record Status	Not Recording	
NTP Status	Disable	
DDNS Status	Success test09.myfoscaml.org	
UPnP Status	Success	
WiFi Status	Not connected	
IR LED Status	Off	

The camera's software will be configured for port forwarding. There may be issues with your routers security settings, and sometimes may error. We recommend you configure port forwarding manually on your router .

4.4.6 Port

This camera supports HTTP Port, HTTPS and ONVIF.





HTTP port: By default, the HTTP and Media are set to 88. Also, they can be assigned with another port number between 1 and 65535. But make sure they can not be conflict with other existing ports like 25, 21. HTTP Port is used to access the camera remotely. If you want to access the camera and view the video, the HTTP Port must both be configured correctly.

HTTPS port: The default port is 443. You can use the url to access the camera: **https:// IP + HTTPS port.**

ONVIF Port: By default, the ONVIF port is set to 888. Also, they can be assigned with another port number between 1 and 65535(except 0 and 65534). But make sure they can not be conflict with other existing ports.

Another way to change the HTTP port NO.


Step 1: Open the Equipment Search Tool, select the camera you would like to change the port of, right click on the IP address, and click on "Network Configuration", this brings up the network configuration box as shown :



Step 2: Enter the username and password of the Administrator (default username is admin with a blank

password), and click “OK” to apply changes.

Step 3: Wait around 10 seconds, you’ll see that the camera’s IP address has changed. In our example it was changed to 2000, so we see http://192.168.8.102:2000 in Equipment Search Tool. Also, the IP address is now fixed at a static IP address of http://192.168.8.102:2000. This IP address will not change even if the camera is powered off and back on, the camera will remain on this IP address. This is very important that a static IP address is set, or you may have problems later with remote access and seeing the camera remotely if the camera loses power and reconnects on a different IP address. Make sure you set a static IP address!




Camera Name	IP Address	Device ID	Type
Anonymous	Http://192.168.1.110:2000	00626E589230	H. 264

Note: Http port and Https port must be different.

If the camera cannot be accessed, please make sure the port forwarding is succeed.

4.4.7 Mail Settings

If you want the camera to send emails when motion has been detected, here Mail will need to be configured.



5 Save Refresh

Enable ☒

SMTP Server	smtp.gmail.com	
SMTP server address supports English, numbers and @ _ . -		
SMTP Port	25	1
Transport Layer Security	STARTTLS	
G-Mail only supports TLS at Port 465 and STARTTLS at Port 587 or 25. Hotmail only supports STARTTLS at Port 587 or 25.		
Need Authentication	Yes	
SMTP Username	test123@gmai.com	2
The maximum length of the user name is 63, support numbers, letters and symbols @ _ . \$ * -		
SMTP Password	
The maximum password length is 32, does not support the character & =		
Sender E-mail	test123@gmai.com	3
		Test 6
First Receiver	test@163.com	
The maximum length of the receiver is 63, support numbers, letters and symbols @ _ . \$ * -		
Second Receiver	tset@hotmail.com	4
Third Receiver		
Fourth Receiver		

1---- SMTP Server/ Port /Transport Layer Security Enter SMTP server for sender. **SMTP** port is usually set as 25. Some SMTP servers have their own port, such as 587 or 465, and Transport Layer Security usually is None. If you use Gmail, Transport Layer Security must be set to TLS or STARTTLS and SMTP Port must be set to 465 or 25 or 587, which port you choose should be decided by which Transport Layer Security you select.

2---- SMTP Username/ password ID account and password of the sender email address

3---- Sender E-mail Mailbox for sender must support SMTP

4---- Receiver Mailbox for receiver need not support SMTP,you can set 4 receivers

5---- Save Click Save to take effect

6---- Test Click Test to see if Mail has been successfully configured.

Click **Test** to see if Mail has been successfully configured.

If the test success, you can see the Success behind the Test, at the same time the receivers will receive a test mail.

4.4.8 FTP Settings

If you want to upload record files and images to your FTP server, you can set **FTP Settings**.

<div>Save</div> <div>Refresh</div>	
FTP Server	<input type="text" value="ftp://192.168.8.150"/> Example:ftp://192.168.1.103/dir The maximum length of the address is 127, does not support the character & =
Port	<input type="text" value="21"/>
FTP Mode	<input type="text" value="PORT"/>
Username	<input type="text" value="yaocuixiang"/> The maximum length of the user name is 63, support numbers, letters and symbols _ @ \$ * - , . # !
Password	<input type="password" value="....."/> The maximum password length is 63, does not support the character & =
<div>Test</div>	<input type="text" value="Success"/>

Figure a

<div>Save Refresh</div>	
FTP server	<input type="text" value="ftp://ftp.mgenseal.com"/> example:ftp://192.168.1.103
Port	<input type="text" value="21"/>
FTP Mode	<input type="text" value="PORT"/> <div>▼</div>
User name	<input type="text" value="deotestge"/>
Password	<input type="password" value="....."/>
Test	<input type="text" value="Success"/>

Figure b

FTP server: If your FTP server is located on the WLAN, you can set as Figure a.

If you have an FTP server which you can access on the internet, you can set as Figure b.

Port: Default is port 21. If changed, external FTP client program must change the server connection port accordingly.

FTP Mode: Here supports two modes: PORT and PASV.

Username/password: The FTP account and password.

Click **Save** to take effect.

Click **Test** to see if FTP has been successfully configured.

4.4.9 P2P

Access the camera by smart phone (Android or iOS operating system)

First of all, you need to open the P2P function of the camera at “Settings-->Network-->P2P.”

P2P

Save Refresh

UID

EXGTAADYNLYRBGPMYR3JA198

Enable P2P

☒

P2P Port

37504

Please search and install Foscam App named **Foscam** on App Store and Google Play for iOS and Android devices, then you can view your camera anywhere, anytime on your smart mobile devices.

4.5 Video

This section allows you to configure Video stream settings, On screen display and Snapshot settings.

4.5.1 Video Settings

There are two ways to set the stream video settings. They are main stream video settings and sub stream video settings.

Video Settings

Save

 Refresh

Main stream video settings

Enhanced Night Vision Definition ☒

Stream Type	HD Mode
Resolution	720P
Bit Rate	2M
Frame Rate	30
Key Frame Interval	30
Variable bitrate	Yes

Sub stream video settings

Stream Type	HD Mode
Resolution	720P
Bit Rate	512K
Frame Rate	10
Key Frame Interval	30

Stream type: There are four types to identify different streams you have set.

Resolution: The camera supports multiple types, For example: 720P, VGA. The higher the resolution is the clearer video will become. But the code flux will become larger too, and it will take up more bandwidth.

Bit Rate: Generally speaking, the larger the bit rate is, the clearer video will become. But the bit rate configuration should combine well with the network bandwidth. When the bandwidth is very narrow, and bit rate is large, that will lead to video can not play well.

Frame rate: Note that a larger frame size takes up more bandwidth. When the video format is 50Hz, the maximum frame rate is 25 fps. When the video format is 60Hz, the maximum frame rate is 30 fps. You should lower frame rate when the bandwidth is limited. Normally, when the frame rate above 15, you can achieve fluently video.

Key Frame Interval: The time between last key frame and next key frame. The shorter the duration, the more likely you will get a better video quality, but at the cost of higher network bandwidth consumption.

Variable Bitrate: The two options are Yes and NO. Select Yes the bit rate is variable, and the highest value isn't higher than Bit Rate Value (2Mbps). Select NO and the bit rate is constant with Bit Rate Value (2Mbps).

4.5.2 On Screen Display

This page is used to add timestamp and device name on the video.

OSD	
 Save  Refresh	
Display Timestamp	Yes 
Display Camera Name	Yes 
Display Temperature & Humidity	Yes 






Display Timestamp: There are two options: Yes or NO. Select Yes and you can see the system date on the video.

Display Camera Name: There are two options: Yes or NO. Select Yes and you can see the device name on the video.

Display Temperature & Humidity: There are two options: Yes or NO. Select Yes and you can see the temperature and humidity on the video.

4.5.3 Snapshot Settings

On this page you can set the snapshot pictures' image quality and the storage path.

 Save  Refresh	
Manual snap Quality	Medium 
Pictures Save To	None 
Enable timing to capture <input checked="" type="checkbox"/>	
Capture interval	10 (5-65535s)
 Schedule	
All	00 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23
MON	
TUE	
WED	
THU	
FRI	
SAT	
SUN	

Manual Snap Quality: Low, Middle and High. The higher the quality, the picture will be clearer.

Pictures Save To: FTP or SD card. If you have done FTP and Alarm settings, when alarming, the camera will snap pictures to the FTP automatically. If you select the FTP, you can set the file name which the picture save to.

Enable timing to capture

To enable capture interval, follow the steps below:

1 Select Enable Motion detection

2 Capture interval: The interval time between two captures.

3 Select the capture time

- Capture anytime
Click the black button up the MON, you will see all time range turn red. When something moving in the detection area at anytime, the camera will capture.
- Specify an capture schedule
Click the week day words, the corresponding column will be selected. For example, click TUE, the all column of TUE turns to red, that means during Tuesday whole day, the camera will capture.
- Press the left mouse and drag it on the time boxes, you can select the serial area,

4 Click Save button to take effect.

4.5.4 IR LED Schedule

You can set the period of time during which the infrared lamp is turned off to prevent your baby from being influenced during sleep. You can also turn off the infrared lamp on the video preview page at any time.

The screenshot shows a web interface titled "IR LED Schedule". At the top right, there are "Save" and "Refresh" buttons. Below the title, the text "IR LED Schedule" is displayed. The main area contains a light blue box with the text "Turn the IR LED off". To the right of this box, there is a time selection area with "From" and "To" labels. The "From" time is set to 08:00 and the "To" time is set to 18:00. Below these time fields is an "Add" button.

4.6 Detector

4.6.1 One Key Alert(Only Fosbaby P1)

On this page, you can turn on or off the alarm function you need.

Setup Wizard

Status

Basic Settings

Network

Video

Detector

One Key Alert

Motion detection

Sound Detection

Temperature Detection

One Key Alert

Save Refresh

Enable One Key Alert ☒

Choose the detection types contained by One Key Alert

Motion Detection ☐

Sound Detection ☐

Temperature Detection ☐

Humidity Detection ☐

4.6.2 Motion Detection

The camera supports **Motion Detection Alarm**, when the motion has been detected, it will send emails or upload images to FTP.

Motion Detection

7 Save Refresh

Enable ☒ 1

Sensitivity	Medium 2
Triggered Interval	15s 3
Action	<div> <div>4</div> <div> Camera Sound <input type="checkbox"/> PC Sound <input type="checkbox"/> Send E-mail <input type="checkbox"/> Take Snapshot <input type="checkbox"/> Time Interval 2s Please set the capture storage location in advance. Recording <input type="checkbox"/> Please set the video storage location in advance. Push message to the phone <input checked="" type="checkbox"/> </div> </div>
	Set Detection Area 5
	Schedule 6

All
00 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23

To enable motion detection, follow the steps below:

To enable motion detection, follow the steps below:

Step 01: Enable Motion detection


Step 02: Sensitivity---- It supports five modes: Lowest, Lower, Low, Medium, and High. The higher the sensitivity, the camera will be more easily alarmed. Select one motion sensitivity.

Step 03: Trigger interval--- The interval time between two motion detections. Here supports

5s/6s/7s/8s/9s/10s/11s/12s/13s/14s/15s. Select one interval time.

Step 04: Select the alarm indicators

When the motion has been detected, the alarm status will turn to Detect alarm.



Alarm Status	Detect alarm
Record Status	Recording
SD Card Status	SD card
SD Card Free Space	3.0G
SD Card Total Space	3.6G
NTP Status	Disable
DDNS Status	Success http://test09.myfoscam.org:88
UPnP Status	Success
WiFi Status	Connected to:foscam-wifi
IR LED Status	Off

There are four alarm indicators:

A Camera Sound

There is an embedded speaker inside the camera, so if you select Ring, when the motion has been detected, the people around the camera will hear beep alarm sound.

B PC Sound

Click it, when the alarm is triggered in FosBaby, your PC opportunity to sound the alarm.

C Send E-mail

If you want to receive alarm emails when motion is detected, you must select send E-mail and set Mail Settings first.

D Take Snapshot

If you select this check box, when the motion has been detected, the camera will snap the live view window as a still picture and load it to the FTP. Make sure you have set FTP and set FTP as the storage path in Video->Snapshot settings panel.

Capture interval: The interval time between two pictures.

E Recording

If you select this check-box, when the motion has been detected, the camera will record automatically and store the record files to the SD Card. Make sure the camera has inserted SD card and you have set the SD card as the Alarm record files storage path, please go to **Record—> Storage** location page to verify

this settings.

The default alarm record time is 30s and pre-alarm record time is 5s, please go to **Record—> Alarm Record** page and change the alarm time settings.

F Push message to the phone

If you select this check-box, when the motion has been detected, the camera will send message to the phone. The phone had installed Foscam APP and through the APP the camera had been added successfully.

Step 05: Set detect area

Click set detect area and it pop up a window, then you can draw the detection area. Click Back button after settings. When something moving in the detection area, the camera will alarm.



Step 06: Alarm Schedule

① Alarm anytime when motion is detected

Click the black button up the MON, you will see all time range turn red. When something moving in the detection area at anytime, the camera will alarm.

Click this button and select all time range.

Detection Area

Schedule

All	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23
MON																								
TUE																								
WED																								
THU																								
FRI																								
SAT																								
SUN																								

② Specify an alarm schedule

Click the week day words, the corresponding column will be selected. For example, click TUE, the all column of TUE turns to red, that means during Tuesday whole day, when something moving in the detection area, the camera will alarm.

Set Detection Area

Schedule

All	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23
MON																								
TUE																								
WED																								
THU																								
FRI																								
SAT																								
SUN																								

③ Press the left mouse and drag it on the time boxes, you can select the serial area.

Set Detection Area

🕒 Schedule

All	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23
MON																								
TUE																								
WED																								
THU																								
FRI																								
SAT																								
SUN																								

Step 07: Click Save button to take effect.

When the motion has been detected during the detection time in the detection area, the camera will alarm and adopt the corresponding alarm indicators.

NOTE: You must set the detection area and detection schedule, or else there is no alarm anywhere and anytime.

4.6.3 Sound Detection

When the ambient sound over a certain decibel ,the sound alarm will be triggered.

Sound Detection

Save
Refresh

Enable ☒

Sensitivity	High
Triggered Interval	5s
Action	<div> Camera Sound <input type="checkbox"/> PC Sound <input type="checkbox"/> </div>
	Send E-mail <input type="checkbox"/>
	<div> Take Snapshot <input type="checkbox"/> Time Interval 2s </div>
	Please set the capture storage location in advance.
	Recording <input type="checkbox"/> Please set the video storage location in advance.
	Push message to the phone <input checked="" type="checkbox"/>

🕒 Schedule

All	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23
MON																								
TUE																								

If the Sensitivity is set to “High”, the camera will detect the sound whose more than 55db.
 If the Sensitivity is set to “Medium”, the camera will detect the sound whose more than 65db.
 If the Sensitivity is set to “Low”, the camera will detect the sound whose more than 75db.
 If the Sensitivity is set to “Lower”, the camera will detect the sound whose more than 85db.
 If the Sensitivity is set to “Lowest”, the camera will detect the sound whose more than 95db.

4.6.4 Temperature Detection

An alarm is triggered when the temperature exceeds the defined safe temperature range. The safe temperature range can be defined by you. However, the lower limit of the safe temperature range must be set to 0°C or higher, the upper limit must be set to 40°C or lower, and the upper limit shall at least be 5°C higher than the lower limit.

Temperature Detection

Save
 Refresh

Enable ☒

Comfortable temperature range	<div style="display: flex; align-items: center;"> <input style="width: 40px; text-align: center;" type="text" value="15"/> ~ <input style="width: 40px; text-align: center;" type="text" value="22"/> °C ▼ </div> <p style="font-size: 0.8em; margin-top: 5px;">It will trigger the alarm if the temperature outside this range.</p>
Triggered Interval	<input style="width: 100px;" type="text" value="5s"/> ▼
Action	<div style="display: flex; justify-content: space-between;"> Camera Sound <input type="checkbox"/> PC Sound <input type="checkbox"/> </div> <div style="margin-top: 5px;">Send E-mail <input type="checkbox"/></div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> Take Snapshot <input type="checkbox"/> Time Interval <input style="width: 40px;" type="text" value="2s"/> ▼ </div> <p style="font-size: 0.8em; margin-top: 5px;">Please set the capture storage location in advance.</p> <div style="margin-top: 5px;"> Recording <input type="checkbox"/> Please set the video storage location in advance. </div> <div style="margin-top: 5px;"> Push message to the phone <input checked="" type="checkbox"/> </div>

Schedule

All	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23



The way to set is the same to set motion detection.



4.6.5 Humidity Detection(For FosBaby P1)


It monitors the humidity in the environment, once it exceeds the range you set up, the camera will send message. However, the lower limit of the safe humidity range must be set to 0% or higher, the upper limit

must be set to 100% or lower, and the upper limit shall at least be 5% higher than the lower limit.

Humidity Detection

 Save  Refresh

Enable <input checked="" type="checkbox"/>	
Comfortable Humidity Range	20 % ~ 45 % <small>It will trigger the alarm if the humidity outside this range.</small>
Triggered Interval	5s 
Action	Camera Sound <input type="checkbox"/> PC Sound <input type="checkbox"/>
	Send E-mail <input type="checkbox"/>
	Take Snapshot <input type="checkbox"/> Time Interval 2s  <small>Please set the capture storage location in advance.</small>
	Recording <input type="checkbox"/> <small>Please set the video storage location in advance.</small>
	Push message to the phone <input checked="" type="checkbox"/>

 Schedule

All

00

01

02

03

04

05

06

07

08

09

10

11

12

13

14

15

16

17

18

19

20

21

22

23



4.7 Record



This section will allow you to change the record files storage path and the record time.

4.7.1 Storage Location

On this page you can change the alarm and manually recording storage path.

Storage Location

 Save  Refresh

Recording Location	FTP 	
Local Recording Location	c:\IPCamRecord	

Recording Location is used for alarm recordings and schedule recordings.

The local recording must be stored in local storage. The default Windows storage location is "c:\IPCamRecord". The default Mac OS storage location is "/IPCamRecord". If you modify the path on other cameras, this default storage location will be modified accordingly.

Alarm Recording Location : SD card, FTP.

Check “SD card” : The video will be saved in SD card. **Make sure the camera has been inserted the SD card.** On this page, you can see the available space of the SD card.

Check “FTP” : The video will be saved in FTP. Please refer to "FTP settings."



Manual Recording Location: For Windows OS, the manual recording path is C:/ IPCamRecord, you can change another one. For MAC OS, the manual recording path is: / IPCamRecord.

4.7.2 Alarm Recording

 Save  Refresh	
Enable Pre-Record <input checked="" type="checkbox"/>	
Pre-recorded Time	5s
Alarm Record Time	30s

4.7.3 Local Alarm Recording

This page you can enable the local alarm record and Local Alarm record time.

Local Alarm Recording	
 Save  Refresh	
Enable Local Alarm Recording <input checked="" type="checkbox"/>	
Local Alarm Recording Time	30s

4.7.4 Scheduled Recording

When the video is selected as FTP, the device supports scheduled recording.

Storage Location	
 Save  Refresh	
Recording Location	FTP
Local Recording Location	c:\IPCamRecord 

Scheduled Recording To FTP

Enable Scheduled Recording ☒

Stream

Main stream

All	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23
MON																								
TUE																								
WED																								
THU																								
FRI																								
SAT																								
SUN																								

When the video is selected as SD card, the device supports pumping frame recording.

Storage Location

Recording Location

SD card

372.2 MB / 7.4 GB

Local Recording Location

c:\IPCamRecord

Scheduled Recording To SD Card

Enable Scheduled Recording ☒

Enable Long-time recording No

Frame Rate 30

Record full strategy Cover

Audio Record No

Stream Main stream

[Edit Scheduled Recording](#)

	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23
All																								
MON																								
TUE																								
WED																								
THU																								
FRI																								
SAT																								

Frame Rate: There are six frame selections, such as 1/30, 4/30, 8/30, 15/30, 24/30, 30/30. Recommended default is 4/30. The greater the Frame rate is, the sharper picture quality is, and the greater of storage space is, the shorter the storage time is.

Record full strategy: When the SD card is full, you can choose to cover the previous recording, or stop recording.

Audio Record: You can choose "yes" or "no".

NOTES:

- Scheduled recording only supports video saved to the SD card or FTP server.
- The schedule recording will stop while alarm recording is beginning ,and it will continue automatically after alarm recording end.
- You can refer to "alarm schedule." in " 4.5 Alarm" about editing the time of recording Schedule.

4.7.5 SD Card Management

This camera supports SD Card and the max size of SD card must be under 32G.

When you plug in the SD card during the camera work process, please reboot the camera again, or else the SD Card may be cannot work well.

Go to the **Settings→Status→Device Status** page, you can see the SD card status.

SD Card Management

Refresh

SD Card Status	SD card	SD Card Management
SD Card Free Space	798.6MB	
SD Card Total Space	7.4GB	

Note: SD card management is only effective when access the IPC in LAN

SD Card Management: After click the button, you should enter the username and password of the camera. Then you can manage the recording files of the camera in the SD card. The SD card management is only effective when access the camera in LAN.

The default storage path of alarm record files is SD card, when the available size of SD card is less than 256M, the old record files will be deleted automatically.

4.8 Lullabies

The only nursery rhyme on the machine and the lullabies of a specified coding mode in the SD card can be played (two lullabies is stored in the Flash for playing when no SD card is available).

When the **Songs Path** is set to **SD**, the IP camera only display five songs in the **Music** list.

Lullabies List

Refresh

Songs Path

SD

Playlist

default

Add
Delete

Note: Songs folder only supports five songs.

Music

Add
Delete
Up
Down

Playlist

Simple playing control is available: Play/stop, previous/next song, in-order playing, circular playing of a single song, circular playing of all songs, and volume control (on the lower part of the video preview page).



Two ways are available for storing the rhyme into an SD card:

1. Remove the SD card from the machine, connect the SD card to the computer using a card reader, and import songs to the card.
2. Insert the SD card into the machine and import songs on the SD card management page.

Note:

Import songs to the SD card and insert the SD card into the camera. If you restart the camera, the songs can be played directly. If you do not restart the camera, you must click the **Synchronize** button on the **Real-time preview** page to play the songs.




4.9 PTZ (For FosBaby P1)

This page will allow you to change the pan/tilt speed and do cruise tracks settings.

4.9.1 Pan & Tilt Speed

There are five PT speed types: very fast, fast, normal, slow and very slowly. Select the desired PTZ speed type and click save button.



4.9.2 Cruise Settings

This section explains how to add/ delete one cruise track.

Setting the Cruise Mode

There are two cruise mode: Cruise time and Cruise Loops.

Cruise time: Select **Cruise time** from **Cruise Mode** drop-down, then you can set the **Cruise time** of the camera.

Cruise Loops: Select **Cruise Loops** from **Cruise Mode** drop-down, you can set the **Cruise Loops** of the camera.

Click **Save** to take effect.

Manage the Cruise Track

There are two default cruise tracks: Vertical and Horizontal.

Vertical: The camera will rotate from up to down

Horizontal: The camera will rotate from left to right.

Add: Add one cruise track, then click save button.

Delete: Select one cruise track and delete it.

Save: After you modify the **Dwell time**, you should click **Save** button to take effect.

Example: How to do add cruise tracks ?

Firstly, Click Add button and enter a descriptive name to identify the cruise track.


Secondly: On the lower left of the page, you can see all preset points you have added. Select one preset point and click Add button, you can see the preset point has been added to the cruise track on the cruise track page. You need to add two or more preset points to the cruise track.

The screenshot displays the 'Cruise Settings' window. At the top, there's a 'Refresh' button. Below it, the 'Cruise Mode' is set to 'Cruise time' and 'Cruise time' is set to '15 Minute'. A 'Save' button is present. The 'Cruise Tracks' section shows a text input field with 'test' and 'OK'/'Cancel' buttons. A red box highlights the input field with the text 'The new added track name.' Below this, there are two panels: 'Preset point' and 'Cruise track'. The 'Preset point' panel lists 'TopMost', 'BottomMost', 'LeftMost' (highlighted in green), and 'RightMost'. A red box highlights 'LeftMost' with the text '1 Select one preset point.' The 'Cruise track' panel shows a table with 'Preset point' and 'Dwell time' columns. It lists 'BottomMost' with '1 Sec' and 'LeftMost' with '2 Sec' (highlighted in green). A red box highlights the 'LeftMost' row with the text 'Here you can see the preset point has been added to one track. And you can set the stay time.' Between the panels are 'Add', 'Up', and 'Down' buttons. A red box highlights the 'Add' button with the text '2 Click Add button.'

Thirdly: Click **OK** button and the cruise track will take effect.

You can add other cruise track as the same method.


For example: I have added three preset points to the "track 1", that means : When I select the "track 1" on the surveillance window, the camera moves as the following track: upright then Right Most last downleft. You can add preset on the left of the surveillance window.



After add the cruise track, back to the surveillance window, click Cruise, here you can see all cruise tracks you have added.



There are other buttons between the Preset points and Cruise track, you can use these buttons to adjust the order of preset points or add/delete one preset points in one cruise track.



Add: Select one preset points and add it to the selected cruise track.

Delete: Select one preset points you have added to one cruise track, click delete.

Move up/ down: Select one cruise track, adjust the order of preset points in one cruise track.

Attention: Considering the life time and thermal issue of the motor, it's not recommend to do long-time cruise.

4.9.3 Start-Up Options

Here section will allow you to set the stop position after the camera reboots.

It supports three modes: Disable Start-Up, Go To Home Position and Go To Preset Position.

Disable Start-Up: When rebooting, the camera will not pan / tilt.

Go To Home Position: When rebooting, the camera will provide Central Management Software to manage or monitor multi-cameras n / tilt and stops at center.

Go To Preset Position: Select one preset position and save it. When rebooting, the camera will pan/ tilt and stops at the preset position you have set.

4.10 Firewall

This section explains how to control the access permission by checking the client PC's IP addresses. It is composed of the following columns: **Block access from these IP addresses** and **Only allow access from these IP addresses**.

IP Address #1	
IP Address #2	
IP Address #3	
IP Address #4	
IP Address #5	
IP Address #6	
IP Address #7	
IP Address #8	

Enable firewall, If you select Only allow access from these IP addresses and fill in 8 IP addresses at most, only those clients whose IP addresses listed in the **Only allow access from these IP addresses** can access the Network Camera. If you select **Block access from these IP addresses**, only those clients whose IP addresses are in the IP list cannot access the Network Camera.

Click **Save** to take effect.

4.11 System

In this panel, you can backup/restore your camera settings, upgrade the firmware to the latest version, restore the camera to default settings and reboot the device.

4.11.1 Back-up & Restore

Click **Backup** to save all the parameters you have set. These parameters will be stored in a bin file for future use.

Click Browse and select the parameters file you have stored, then click Submit to restore the restore the parameters.

The screenshot shows a web interface titled "Back-up & Restore". Below the title, there is a text box stating: "Backup is used to save your current settings. It is recommended to backup your configuration before modifying or upgrading firmware." Below this text is a large blue button labeled "Backup". Underneath, another text box says: "Settings can be restored by uploading the backup file." Below this is a form with a "Path:" label, an empty text input field, a "Browse..." button, and a "Submit" button.

4.11.2 System Upgrade


Your current firmware version will be displayed on your screen. You may go to the **Status → Device Information** Page to check for the latest firmware versions available.

Click **Browse**, choose the correct bin file and then click **System upgrade**. Make sure you have unplugged the SD card.

Don't shut down the power during upgrade. After upgrading, you can see the upgrade result.

The screenshot shows a web interface titled "System Upgrade". At the top, there is a blue button labeled "Download the latest firmware" and text indicating "Current Firmware Version: 2.22.1.218". Below this is a form with an empty text input field, a "Browse..." button, and a "System Upgrade" button. At the bottom of the form is a "Result" label followed by an empty text input field. Below the form, a message states: "Your camera will reboot during the firmware upgrade."

Upgrade Firmware by Equipment Search Tool

Double click the Equipment Search Tool shot icon , select the Camera IP that you want to upgrade the firmware. Then select Upgrade Firmware and enter the username and password, choose the firmware file, and upgrade.





Figure 4.1



CAUTION: If your camera works well with the current firmware, we recommend not upgrading. Please don't upgrade the firmware unnecessarily. Your camera may be damaged if misconfigured during an upgrade.

NOTE:

Before upgrade the firmware, please unplug the SD card and reboot the camera, don't upgrade the firmware in WAN through the web UI, or else the upgrade process may be failed.

Please ensure you have download the correct firmware package for your camera before upgrading. Read


the upgrade documentation in the upgrade package before you upgrade.

Upon downloading the firmware check the sizes of the bin files. They must match the size in the read me.txt file. If not, please download the firmware again until the sizes are the same. Your camera will not function correctly if a corrupt .bin file is used.

Normally, only Device WEB UI need to be upgrade, please do not try to upgrade the Device System Firmware.

- 1) Never shut down the power of the camera during upgrade until the IP camera restart and get connected.
- 2) After upgrade successfully, please uninstall the old plugin and re-install it, then reset the camera to the default factory settings before using the camera.

4.11.3 Patch Installation



The screenshot shows a web interface titled "Patch Installation". It features a file input field with a "Browse..." button and an "Install Patch" button. Below these is an "Uninstall Patch" button. A "Result" label is followed by an empty text box. At the bottom, a message states: "Your camera will reboot when you install/uninstall patch."

4.11.4 Factory Reset


Click All reset and all parameters will return to factory settings if selected. This is similar to press the Reset button on the bottom of the camera.



The screenshot shows a web interface titled "Factory Reset". It contains a "Factory Reset" button and a text instruction: "Click this button to reset the camera to factory default."

4.11.5 Reboot


Click Reboot System to reboot the camera. This is similar to unplugging the power to the camera.



The screenshot shows a web interface titled "Reboot". It contains a "Reboot" button and a text instruction: "Click this button to reboot your camera."

5 Playback

On this page you can view the record files stored in the SD card.



Section 1 Define the Record files time and Type

Directory : The storage path of record files

Time : Here supports three types: current day, current month and All records. Another way, select the time on the time&date manually.



Type : The type of records files, Here supports two types: Normal record, Alarm record and All records.



: Click this button to search all record files satisfy the conditions you selected.

Continuous Play: Select the checkbox to play continuously all the record files.

Section 2 Search record files

On this panel you can see all record files satisfy the conditions you set.

Section 3 Play/Stop/Audio/Full screen buttons

Please select one record file before use these buttons.



Click this button to play the record files



Click this button to stop the record files



Open or stop audio




Click this button to make full screen, and double click left mouse to exit full screen.



6 Appendix



6.1 Frequently Asked Questions


NOTE: Any questions you would meet, please check Network connections firstly. Check the working status revealed by the indicators on the network server, hub, exchange and network card. If abnormal, check the network connections.

6.1.1 Install the add-on of Firefox browser, Google Chrome and IE Chrome.












6.1.2 Uninstall the add-on of Firefox browser, Google Chrome and IE Chrome.





6.1.3 I have forgotten the administrator password

To reset the administrator username and password, press and hold down the RESET BUTTON for 5 seconds. Upon releasing the reset button, wait for 20 seconds, the camera will reboot and the username and password will return to the factory default administrator username and password. Please power on the camera before reset

Default administrator username: admin

Default administrator password: No password

6.1.4 Camera can not record

When you use Windows7 or Vista, you may be not able to do manually record or change the record path because of the security settings of computer.

There are two ways to resolve this problem:

Please add the camera as a trusted site to resolve this issue. The steps are :

IE browser→Tool→Internet Properties→Security→Trusted sites→Sites→Add

Open IE browser, then right click, select "Run as administrator"

6.1.5 Subnet does not match

Check whether your ipcamera in the same subnet of your computer. The step is **Control Panel** → **Network Connections** → **Dbclick Local Area Connections** → Choose **General** → **Properties**. Check subnet mask, IP address and gateways. When you set IP address please make sure they are in the same subnet. Otherwise you can't access camera.

6.1.6 No Pictures Problems


The video streaming is transmitted by the ActiveX controller. If ActiveX controller isn't installed correctly you will see no video image. You can resolve this problem by this way:

Download ActiveX controller and set the safety property of IE in the PC when you view it first time: IE browser → Tool → Internet Proper → Security → Custom Level → ActiveX control and Plug-ins. Three options of front should be set to be "Enable", The ActiveX programs read by the computer will be stored. As follows:

Enable: Download unsigned ActiveX controls

Enable: Initialize and script ActiveX controls not marked as safe

Enable: Run ActiveX controls and plug-ins



If you allow the ActiveX running, but still could not see living video. Please change another port number to try. Don't use port 88.

<div> <div>Save</div> <div>Refresh</div> </div>	
HTTP Port	88
HTTPS Port	443
ONVIF Port	888

NOTE: Make sure that your firewall or anti-virus software does not block the camera or ActiveX. If you could not see video, please shut down firewall or anti-virus software to try again.

6.1.7 Can't access IP camera in internet

There are some reasons:

- 1、ActiveX controller is not installed correctly
- 2、The port which camera used is blocked by Firewall or Anti-virus software. Please change another port number and try again.
- 3、Port forwarding is not successful

Check these settings and make sure they are correct.

6.1.8 UPnP always failed

UPnP only contains port forwarding in our recent software. Sometimes, it may be failed to do port forwarding automatically because of firewall or anti-virus software. It also has much relation with router's security settings. So we recommend you do port forwarding manually. You can view your camera in internet successfully after you do port forwarding manually in your router.

6.1.9 Camera can not connect wireless

If your camera could not connect wireless after you set wireless settings and plug out the cable. Please check whether your settings are correct or not.

Normally, camera can't connect wireless mainly because of wrong settings.

Make sure broadcast your SSID; use the same encryption for router and camera.

6.1.10 Can't see other cameras listed in multi-device when using remote access

If you want to view all the cameras via the WAN, verify that each camera added in the multi-device settings can be accessed by using the DDNS name and port number. Use the DDNS domain name not the camera's IP. (For more details see: How to add cameras in WAN)

6.2 Default Parameters

Default network Parameters

IP address: obtain dynamically

Subnet mask: obtain dynamically

Gateway: obtain dynamically

DDNS: Embedded FOSCAM domain name

Username and password

Default admin username: admin with a blank password

6.3 Specifications

ITEMS		Fosbaby
Image Sensor	Sensor	High Definition Color CMOS Sensor
	Display Resolution	1.0M Pixels(1280*720)
	Min. Illumination	0 Lux (With IR Illuminator)
Lens	Lens Type	M12 interface f 2.5mm F=1.8
	focal length	f 2.5mm
	Aperture	F=1.8
	Diagonal angle of view	100°
	Horizontal view angle	90°
Video	Image Compression	H.264
	Image Frame Rate	30fps(60Hz), 25fps(50Hz), downward adjustable
	Resolution	720P(1280 x 720), VGA(640 x 480) & (640 x 360), QVGA(320 x 240) & (320 x 180)
	Stream	dual stream
	Image adjustment	The hue, brightness, contrast, saturation, sharpness are adjustable
	Flip image	flip and mirror
	Infrared mode	Automatic or manual
	IR Range	IR Range up to 5m(16.4ft)
Network	Ethernet	N/A
	Wi-Fi	IEEE 802.11 b/g/n
	Modulation Mode	OFDM/DBPSK/DQPSK/CCK
	Frequency	2.412-2.484
	Antenna	All directional
	Soft AP	Connect to Clients Directly via Wi-Fi
	WPS	one button push wireless connection
	Network Protocol	IP、TCP、UDP、HTTP、HTTPS、SMTP、FTP、DHCP、DDNS、UPnP、RTSP、WPS
System Requirements	Operating System	Microsoft Windows 2000/XP, Vista, 7,8; Mac OS
	Browser	Microsoft IE8 and above version or compatible browser; Mozilla Firefox; Google Chrome; Apple Safari.

Other Features	Motion Detection	Alarm via Smartphone App, E-Mail, upload alarm snapshot to FTP
	Sound Detection	
	Temperature Detection	
	Playing lullabies	Playing lullabies via Smartphone App or Web Client, new lullaby required to be put into Micro SD card
	Two-way Audio	Supports Two-way Audio via Smartphone App or Web Client
	WiFi LEDs	Supports turn on/off via Smartphone App or Web Client
	Privacy Block	Set privacy area manually
	External Card Slot	Micro-SD up to 32G
	User Accounts	Three levels user role
	Firewall	Supports IP Filtering
	Reset	Reset button is available
Power	Power Supply	DC 5V/1.5A
	Power Consumption	<7.5 Watts
Physical	Dimension(LxWxH)	75(L)x 71(W)x 119(H)
	Net Weight	140g
Environment	Operating Temperature	-10°C ~ 50°C (14°F ~ 122°F)
	Operating Humidity	20% ~ 85% non-condensing
	Storage Temperature	-20°C ~ 60°C (-4°F ~ 140°F)
	Storage Humidity	0% ~ 90% non-condensing
Certification	IC、CCPSA、CSA、CE、FCC、RoHS	

ITEMS		Fosbaby P1
Image Sensor	Sensor	High Definition Color CMOS Sensor
	Display Resolution	1.0M Pixels(1280*720)
	Min. Illumination	0 Lux (With IR Illuminator)
Lens	Lens Type	M12 interface f 2.5mm F=1.8
	focal length	f 2.5mm
	Aperture	F=1.8
	Diagonal angle of view	100°
	Horizontal view angle	90°
Video	Image Compression	H.264
	Image Frame Rate	30fps(60Hz), 25fps(50Hz), downward adjustable
	Resolution	720P(1280 x 720), VGA(640 x 480) & (640 x 360), QVGA(320 x 240) & (320 x 180)
	Stream	dual stream
	Image adjustment	The hue, brightness, contrast, saturation, sharpness are adjustable

	Flip image	flip and mirror
	Infrared mode	Automatic or manual
	Pan/Tilt Angle	Horizontal:320° & Vertical: 100°
	IR Range	IR Range up to 8m(26.2ft)
Network	Ethernet	N/A
	Wi-Fi	IEEE 802.11 b/g/n
	Modulation Mode	OFDM/DBPSK/DQPSK/CCK
	Frequency	2.412-2.484
	Antenna	All directional
	EZlink	Link to WiFi network easily
	Soft AP	Connect to Clients Directly via Wi-Fi
	WPS	One button push wireless connection
	Network Protocol	IP、TCP、UDP、HTTP、HTTPS、SMTP、FTP、DHCP、DDNS、UPnP、RTSP、WPS
System Requirements	Operating System	Microsoft Windows 2000/XP, Vista, 7,8; Mac OS
	Browser	Microsoft IE8 and above version or compatible browser; Mozilla Firefox; Google Chrome; Apple Safari.
Other Features	Motion Detection	Alarm via E-Mail, upload alarm snapshot to FTP
	Sound Detection	
	Temperature Detection	
	Humidity Detection	
	Playing lullabies	Playing lullabies via Smartphone App or Web Client, new lullaby required to be put into Micro SD card
	Two-way Audio	Supports Two-way Audio via Smartphone App or Web Client
	Cloud Service	Synchronously manage all your cameras, watch live videos
	Night Lamp	Supports turn on/off via Smartphone App or Web Client
	WiFi and System LEDs	Supports turn on/off via Smartphone App or Web Client
	Privacy Block	Set privacy area manually
	External Card Slot	Micro-SD up to 32G
	User Accounts	Three levels user role
	Firewall	Supports IP Filtering
	Reset	Reset button is available
Power	Power Supply	DC 5V/2A
	Power Consumption	<9 Watts
Physical	Dimension(LxWxH)	83(L)x 65(W)x 128(H)

	Net Weight	200g
Environment	Operating Temperature	-10°C ~ 50°C (14°F ~ 122°F)
	Operating Humidity	20% ~ 85% non-condensing
	Storage Temperature	-20°C ~ 60°C (-4°F ~ 140°F)
	Storage Humidity	0% ~ 90% non-condensing
Certification	CE, FCC, RoHS	

Attention: Power adapter should be used between 0°C-40°C, and 5%-90% relative humidity.

6.4 CE & FCC

Electromagnetic Compatibility (EMC)

FCC Statement



This device complies with FCC Rules Part 15. Operation is subject to the following two conditions.

- ◆ This device may not cause harmful interference
- ◆ This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the installation manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is like to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

FCC Caution

Any changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CE Mark Warning



This is a Class B product. In a domestic environment, this product may cause radio interference, in which case

the user may be required to take adequate measures.

6.5 Warranty

FOSCAM values your business and always attempts to provide you the very best of service.

No limited hardware warranty is provided by FOSCAM unless your FOSCAM product ("product") was purchased from an authorized distributor or authorized reseller. Distributors may sell products to resellers who then sell products to end users. No warranty service is provided unless the product is returned to an authorized return center in the region where the product was first shipped by FOSCAM or to the point-of-purchase, which may have regional specific warranty implications.

If you purchase your FOSCAM product from online store, please contact the point-of-purchase and ask for return/replacement/repair service.

Limited Hardware Warranty

- FOSCAM products are warranted to be free from manufacturing defects in materials and workmanship starting from the shipping date of FOSCAM.

This limited hardware warranty does not cover:

- Software, including the software added to the products through our factory-integration system, software that included in the CD, etc.
- Usage that is not in accordance with product instructions.
- Failure to follow the product instructions.
- **Abuse firmware upgrade without the authorized technician's guidance.**
- **Normal wear and tear.**

Return Procedures

- Please read FOSCAM warranty policy & policy of your reseller first before sending items back to point-of-purchase.
- Customer must first contact point-of-purchase to obtain a Return Merchandise Authorization (RMA) number before returning the product. If the product you received is suspected to be defective and the product warranty has not expired, The RMA number will allow your reseller to track your return much easier and help them expedite processing your request.
- After receiving your RMA case number, pack the item(s) very well with the original box and all the original accessories included such as power adapters, brackets, cables, manuals, and driver CD disks.
- Write your RMA number and the return reason (the problem of the product) on the warranty card along with the complete package to send them back.

Replacement Services

- **If customers ask for replacement service, please contact point-of-purchase and follow their policy.**
- Our technicians will inspect all items returned for replacement requests. If the returned product is found in working order, we will return the same item received. However customers shall be responsible for all shipping & handling charges incurred for getting the units back to customers.
- If returned products are found defective, we will replace the product and assume the shipping cost for sending back the replacement unit to customers.
- If for any reason, we are unable to provide a replacement of the original returned item(s). You will have a

choice for a “Substitute” item at the same equal value.

- We do not provide exchange and replacement due to normal hardware upgrade according the market after 14 days after the product is delivered.
- Our technicians will test the product before send out the replacement, any other demand for more than two times replacement for the same product during replacement limit will be rejected.
- **Replaced products are warranted from the balance of the former warranty period.**

Warranty Forfeiture

- Warranty is void if purchase from unauthorized distributor or reseller.
- Warranty is void if trade-mark, serial tags, product stickers have been removed, altered or tampered with.
- Warranty is void for mishandling, improper use, or defacing the product.
- **Abuse firmware upgrade without the authorized technician's guidance.**
- Warranty is void for physical damage, altered, either internally or externally, improper or inadequate packaging when returned for RMA purposes.
- Warranty is void if damage has resulted from accident, dismantle, abuse, or service or modification by someone other than the appointed vendor, souse, fission or the spare part has been over the period of warranty.
- Warranty is void if product is damaged due to improper working environment or operation. (For example, improper temperature, humidity, unusual physical or electrical stress or interference, failure or fluctuation of electrical power, static electricity, using wrong power adapter, etc.)
- Warranty is void if damaged by the use of parts not manufactured or sold by FOSCAM.
- Damage caused by improper installation of third-party products.
- Warranty is void if damaged for irresistible cause, such as earthquake, fire, lightning, flood, etc.
- Product beyond limited warranty.

Shipping Fee

- If products are defective or damaged under normal use or operation in the replacement limit, distributors or resellers are responsible for the shipping cost the product back to customers, customers should assume the shipping cost send the product to the point-of-purchase.
- During replacement limit, if customers ask for replacement due to the product does not fit for customer's personal expectation, customers should responsible for both shipping fee.
- Customers shall be responsible for both shipping fee if their product beyond the replacement limit but still in warranty limit.

Repair Service Out Of Warranty

- FOSCAM provide extra repair service for product that out of warranty, it is chargeable. The total fee contains device cost and service fee. Device cost (including accessories) is the standard uniform price provide by FOSCAM.
- Different region may have different service fee, please contact the point-of-purchase to confirm that before you ask for this service.
- Our technicians will quote the total price after detect the product, If customers refused to repair after the quotation, customers need pay for the test fee, \$3.5/hour. If agree with the quotation, test will be free.
- Repaired product out of warranty will obtains 3-month warranty from the date of the product back to customers.

Limitation of Liability

- FOSCAM is not responsible for other extra warranty or commitment promised by resellers, if your reseller promised some extra commitment or warranty; please ask for written documents to protect your rights and interests.
- FOSCAM does not offer refunds under any circumstances. Please contact the point-of-purchase and follow their refund/return policy.
- FOSCAM shall not be liable under any circumstances for any consequential, incidental, special or exemplary damages arising out of or in any connection with this agreement or the products, including but not limited to lost profits, or any claim based on indemnity or contribution, or the failure of any limited or exclusive remedy to achieve its essential purpose or otherwise. Purchaser's exclusive remedy, as against FOSCAM, shall be the repair or replacement of defective parts. If FOSCAM lists a product on its website specification in error or that is no longer available for any reason, FOSCAM reserves the right to explain it without incurring any liability.

All rights reserved. FOSCAM and the FOSCAM logo are trademarks of ShenZhen FOSCAM Intelligent Technology Limited., registered in the U.S. and other countries.

6.6 Statement

You are advised to be cautious in daily life, keep personal account information carefully, do not share personal account easily. Change passwords of your account and equipment periodically, and upgrade equipment firmware to strengthen security consciousness.

Our company makes no warranty, implied or otherwise, that this product is suitable for any particular purpose or use. You need to abide by the relevant laws and regulations of the use restrictions when using Foscam cameras. Our company takes no responsibility of illegal activities by using our products.

Our company takes no responsibility of the loss by force majeure, such as failure or faults of telecom system or the Internet network, computer viruses, malicious attacks of hackers, information damage or loss, and faults of computer system.

Foscam company does not need to take any responsibility of the special, incidental or corresponding loss by the products of our company or any software provide by our company, including but not limited to operating loss, profit or purpose. The company only takes the responsibility applicable to national and local legal requirements.

Our company takes no responsibility of the loss caused by the following at any time:

- 1) loss of purchases;
- 2) loss of intangible property damage, such as data, programs;
- 3) loss of compensation claimed by third-party customers.

Delete images, format the memory card or other data storage devices does not completely remove the original

image data. You can restore deleted files from discarded the storage device by commercial software, but which will potentially lead to personal image data used maliciously by others. The privacy of the data security belongs to user responsibility, the company takes no responsibility.

Parts mentioned in this statement should not be understood by the configuration description of the product purchased by the customer, the product configuration must accord to the specific models purchased by the customer.

Without the prior written permission of Foscam company, all the contents of relevant operating instructions manual affiliated to the product must not be reproduced, transmitted, transcribed or stored in a retrieval system, or translated into other languages.

Our company will reserve the right to improve and modify the product and corresponding manuals. The company reserves the right of final interpretation on our products.

7 Obtaining Technical Support

While we hope your experience with the IPCAM network camera is enjoyable and easy to use, you may experience some issues or have questions that this User's Guide has not answered.

If you have problem with FOSCAM IP camera, please first contact FOSCAM reseller for solving the problems.

If our reseller cannot provide service, please contact our service department: tech@foscam.com



CE Certificate Website: <http://www.foscam.com/company/ce-certificate.html>