Upgrade Guide for NVR
FNA108HE/FN9116HE/H/FN9132HE/H

This firmware is for NVR FNA108HE/FN9116HE/H/FN9132HE/H, please check your NVR modelon the sticker. Updating with the wrong firmware could severely damage and/or break your NVR.

Method 1: Update firmware on Foscam VMS.

Step1: Log-in your NVR on Foscam VMS, go to **System → System Upgrade** Click **Browse** → choose the **FOSCAM_MC6850_NVR_6.1.38.140000_4G_update.update** file, click **Open** → click **Upgrade**.

Step 2: "**Upgrading, do not power off … Xs**" pop up.
Then NVR will reboot itself, DO NOT power off NVR. Please wait for NVR re-connection after firmware upgraded.

Step 3: Log-in your NVR again to check the **Firmware Version.**

Method 2: Upgrade firmware on **Monitor with USB disk**.

Step1: Copy the **FOSCAM_MC6850_NVR_6.1.38.140000_4G_update.update** file to USB disk main directory, insert the USB disk to the NVR.

Step2: Log-in your NVR on Monitor, right click and go to **Main Menu→ Upgrade → Refresh** to find the firmware file to do the upgrade.

Note: During upgrading, NVR will reboot itself, DO NOT power off the NVR.

Step3: After upgrading, right click and go to **Info→Version** to check your NVR **Firmware version.**

End

--- by Foscam Technical Support Team