

Upgrade Guidance for HD Cameras

This firmware is for HD cameras This firmware is for HD cameras C1, C1 V2, C1-Lite, C1-Lite V2, FI9800P, FI9800P V2, FI9803PV2, FI9803P V3, FI9816P, FI9816P V2. Please check your camera model on the bottom sticker.


Please check your camera model on the bottom sticker. Updating with the wrong firmware could severely damage and/or break your camera. Please make sure the firmware is correct.

Note:

System firmware 1.9.x.18, App firmware 2.x.1.28, 2.x.1.30, 2.x.1.32, 2.x.1.36, 2.x.1.37, 2.x.1.39, 2.x.2.5, 2.x.2.16, 2.x.2.33, 2.x.2.37, 2.x.2.41, 2.x.2.43, 2.x.2.46, 2.x.2.47, 2.x.2.49, 2.x.2.50 can upgrade to this version.

If camera's system firmware is lower than 1.9.3.18, please upgrade the "FosIPC_E_sys_ver1.9.3.18.bin" first.

If camera is upgraded to this firmware, it cannot be downgraded to previous firmware versions.



Preparation before upgrading:

1. Please restart your camera before the upgrading;
2. If the camera has an Ethernet port, please connect it to the router with an Ethernet cable before upgrading.
3. DO NOT upgrade firmware over internet, just finish it in LAN;
4. Keep power on during the upgrading;

Step 1: Login your camera from Foscam VMS, go to **Settings-->System-->System Upgrade**. Click Browse/Choose File, find the file **FosIPC_E_app_ver2.x.2.53.bin** you've extracted in your local hard driver, then click **Open**. Camera will upgrade after you click on **System Upgrade**.

Step 2: After that completed, please go to check if the firmware version becomes the latest.

Congratulations, your camera successfully upgraded to the latest firmware!

--- By Foscam Technical Support Team