FOSCAM
home security

Quick Setup Guide


WiFi Extender and Chime




To view this guide in other languages (e.g. Español, Français, Deutsch, Nederlands), and for detailed manuals, tools, etc., please visit **foscam.com/downloads**, or scan the QR code:


V1.0

1. Physical Description





2. Indicator Light Descriptions



Indicator light	Status	Indication
1	Power on	Red light on
	In the configuration mode	Blue light flashing
	Working	Blue light on
	Network error	Red light flashing
2 3 4	Signal light	Indicator 2 to 4, the more the number of lights, the stronger the network signal

3. Setting Up Your WiFi Chime: Connection via the Foscam App

Before You Get Started

Scan the QR code below to download and install the Foscam APP.

Available on the App Store

ANDROID APP ON Google play

To ensure a smoother video experience on your smart phone, it is recommended that your smart phone meet the following specifications:

- iOS: version 11 or higher.
- Android: 4.1 or higher, using a device with a Graphics Processing.

Note: For the best experience, please update the APP to the latest version!


■ WiFi Configuration

Please Note:
WiFi Chime does not need to plug in the internet cable.


1. Power on the WiFi Chime, and wait for a few minutes until hearing "**Ready for WiFi configuration**", then, you will see the blue light is flashing.



Note: If anything goes wrong, please press and hold the "Reset" button on the bottom of the WiFi Chime for more than 10 seconds.




2. Make sure that your smart phone is connected to your WiFi router.




3. Open the foscam APP and please sign up for a Foscam account, or sign in if you have one already.



4. Follow the steps below:





Important:
Please turn up the volume of your phone and approach to the WiFi Chime.







Congratulations!
The WiFi Extender can be used now.
Default Info:
SSID: xxxx_5G/2.4G
Password: Same as your router password.

If needed to change, please refer to the left picture.

4. How to link Foscam doorbell with WiFi Chime




It can be accomplished by configuring an automation: when someone presses the doorbell, the Chime will ring synchronously.

Note:


- Please make sure you have added the Foscam doorbell and Foscam Chime to the APP.
- To ensure the correct execution of the automation, please upgrade the doorbell to the latest firmware.
- If you cannot find the added doorbell when creating the smart condition, please reset and delete the doorbell and add it again.


1. Create condition: press the doorbell
















2. Add task: the Chime rings









3. Save it





Make sure that the switch of the automation is turned on and the devices are online, then the Chime will ring synchronously after pressing the doorbell.

5. FAQ

Q: How to do when you do not hear "WiFi Connecting" after scanning the QR-code during WiFi setup stage?

A: Make sure that your cellphone is close to the WiFi Chime (within 1 meter) and the surrounding environment is relatively quiet, then reset and re-add it in Foscam app.

Q: After set up the WiFi Chime smart linkage(such as your Foscam doorbell and the Chime linkage), how to do when the WiFi Chime does not respond after the event is triggered (such as when your Foscam doorbell is pressed)?

A: Make sure that your router connect to the internet; If the WiFi Chime's status indicator is still not in a steady blue state, please reset and re-add it in Foscam app.

Q: Can WiFi Chime improve my WiFi speed?

A: All WiFi extenders can only increase the coverage range of the WiFi network.

Q: How to do if my WiFi Chime often loses connection?

A: Please reduce the distance between your router and the WiFi Chime. It is recommended that at least two indicators of signal light are on.

Q: Can the WiFi Chime be used as a wired extender?

A: Yes. For more details, please search WiFi Chime via link: https://www.foscam.com/faqs/index.html or scan the QR code below:





support@foscam.com

FOSCAM
home security

CE Certificate statement Website:
https://www.foscam.com/company/ce-certificate.html

Exporter and Importer Information Opened to Public:
https://www.foscam.com/company/open-information.html

Manufacturer: Shenzhen Foscam Intelligent Technology Co., Ltd
Addr: Room 901, Unit B, Building 7, Xingke 1st Street
Vanke Cloud City Phase 1, Nanshan Dist., Shenzhen, 518055, China

www.foscam.com

Due to from product upgrades and other reasons, this guide may be slow to update, resulting in slight inconsistencies with the official website information. Please take the official website (www.foscam.com) information as the current standard.